

HR7761/01

- Disc inserts to slice, shred and granulate
- Sturdy base stands stable, even during kneading
- Dishwasher safe accessories
- Break-resistant jar for intensive use

Highlights

Powerful processing



This Philips Food Processor offers a powerful motor with 2 speeds and pulse, providing power and control to prepare all your favorite recipes.

PowerChop technology



PowerChop technology is a combination of blade shape, cutting angle and inner bowl that provides a superior chopping result in both soft and hard ingredients. It is also perfect for making purées and mixing your cake batters!

Accessories for 28+ functions



The - dishwasher safe - accessories are a kneading tool to mix and knead batter and dough. A stainless steel chopping knife to prepare meat and vegetables. Various disc inserts to handle shredding and grating. Break resistant blender of 1L for blending, crushing and stirring different ingredients. An emulsifying disc to prepare food like whipped cream and mayonnaise. A chopper mill to grind e.g. coffee beans

Break-resistant jar



A 1.75-liter break-resistant jar has a working capacity of 1 liter for up to up to 5 smoothie portions at once.

Up to 5 portions in one go



The generous 2.1L bowl (1.5 L working capacity) enables you to blend up to 5 portions of soup in one go.

Color coded accessories/speeds

Match the color of the speed with the color of the accessory for optimized results.

Form fitting couplings & tools



This Philips food processor is designed to be very easy to assemble. Its parts simply click together thanks to the clever form fitting design of the accessories.

Steel disc inserts



Simply select the right disc insert (slicing, shredding, granulating) to prepare your favorite food and click it on the disc holder.

Dishwasher safe accessories



Dishwasher safe accessories

Sturdy base



Sturdy base stands stable, even during kneading

2 speed settings and pulse



For best results, use the low speed setting (speed 1) to whip cream, beat eggs, create pastries and bread dough. The higher speed setting (speed 2) is well suited to chop onions and meats, blend soups and smoothies or shred, slice, grate or rasp vegetables.

Specifications

Accessories

Included: Blade unit S-blade, Coarse shredding tool, Coarse slicing tool, Emulsifying tool, Fine shredding tool, Fine slicing tool, Granulating tool, Jar, Julienne tool, Kneading tool, Mill

Technical specifications

Power: 750 W
Cord length: 1.0 m
Voltage: 220-240 V
Capacity bowl: 2 L
Frequency: 50-60 Hz
Working capacity bowl: 1.5 L
Capacity jar: 1.75 L
Working capacity jar: 1.0 L

Capacity mill: 250 ml
RPM blender (max): 21000 rpm
RPM bowl (max): 1900 rpm

Design

Color: Oyster metallic

Weight and dimensions

Dimensions of product (LxWxH):
210x210x368 mm

General specifications

Number of speed settings: 2 + pulse
Product features: Integrated cord storage, Non-slip feet, Pulse

Finishing

Material of main body: Plastic ABS
Material accessories: Stainless steel
Material jar: Plastic SAN

Service

2-year worldwide guarantee

Sustainability

Packaging: > 90% recycled materials
User manual: 100% recycled paper

