

Philips Triathlon
Wet and dry vacuum
cleaner

FC6844



Be prepared

Cleans three-in-one: wet, dry and shampoo

If you want to be prepared for every cleaning task, the Philips Triathlon is the vacuum cleaner for you. With the Triathlon you can clean dry dust and dirt, wet spills and even rejuvenate your carpets. An all-in-one cleaning solution!

Outstanding results on carpets and furniture

- Turbo Brush nozzle removes 25% more hairs and dust

Easily remove dry dust and dirt

- 1500 Watt motor generating 300 Watt max. suction power

Wet nozzle with brush takes care of sticky dirt

- Wet nozzle brushes, cleans and leaves the floor dry and safe

Extend the lifetime of your carpet

- Deep clean your carpets with shampoo

Ergonomic tube for ease of use

- Tri-scopic tube is fully adoptable to each height

PHILIPS

Specifications

Performance

- Input power (IEC): 1300 W
- Airflow (max): 54 l/s
- Vacuum (max): 24 kPa
- Input power (max): 1500 W
- Suction power (max): 300 W
- Noise level (Lc IEC): 79 (dry cleaning) dB

Design

- Colour: Raven black/translucent

Usability

- Tube coupling: Button
- Action radius: 11.5 m

- Tube type: Stainless steel 3pc telescopic
- Wheel type: Plastic

Nozzles and accessories

- Standard nozzle: Wheeled all-purpose nozzle
- Accessories included: Brush, Crevice tool, Small nozzle
- Accessory storage: On tubeclip
- Additional nozzle: Double injection nozzle, mopper, upholstery nozzle, Turbo brush

Filtration

- Dust capacity: 10 L
- Exhaust filter: Super Clean Air HEPA 12 filter
- Capacity for liquids: 9 L

Highlights

1500 Watt motor

Efficient 1500 Watt motor generates 300 Watt max. suction power for a beautiful cleaning result.

Wet nozzle brushes, cleans and dries

Wet nozzle with brush to take care of the sticky dirt; a mop for cleaning spills and a squeegee to leave the floor dry and safe.

Deep clean your carpets with shampoo

Carpet nozzle with shampoo function to deep clean your carpets.

Tri-scopic tube is fully adaptable to each height



Tri-scopic tube is fully adaptable to each height.

Turbo Brush nozzle



The Turbo Brush nozzle allows deep cleaning of carpets and quick hair and fluff removal from carpets. The rotating brush actively removes small dust particles and hairs, resulting in a 25% better cleaning performance on carpets. The wheels of the nozzle prevent damage during use on hard floors.



Issue date 2023-04-13

Version: 1.0.1

© 2023 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com