



Philips PerfectCare Aqua
Steam generator iron

6 bar

320 g steam boost
Carry lock
2.5-l fixed water tank

Ultra fast ironing

with no temperature adjustment required

Iron any ironable garment from silk, to linen, to cotton, to cashmere...in any order, without having to adjust. Your Philips PerfectCare Iron delivers fast results without risk of burn or shine for all your garments. Truly simple ironing.



GC8643/30

Fast and powerful ironing

- Saving energy with ECO mode
- Tap water-friendly, refill any time during ironing
- Automatically turned off for peace of mind and energy saving
- Our best gliding soleplate
- Ready to use in 2 minutes with unlimited refill
- Large 2.5 l fully visible water tank
- Lock your iron securely to the base station
- Descale your appliance effectively and easily to prolong its lifespan
- Steam boost of up to 320 g

Carefree ironing, no temperature setting required

- Iron everything from jeans to silk with no temperature setting required
- Safe to leave the hot soleplate on the ironing board

PHILIPS

Highlights

OptimalTEMP technology



Now you can iron everything from jeans to silk with no temperature setting required. Guaranteed no burn on all ironable fabrics. Revolutionary technology with both the Advanced Smart Control Processor, which precisely controls the soleplate temperature so that you don't need to, and the powerful cyclonic steam chamber, which delivers consistent, powerful steam, making ironing easier and faster.

Energy saving



By using ECO mode and a reduced amount of steam, you can save energy without compromising on the ironing results.

Steam boost of up to 320 g

The steam boost can be used for vertical steaming and tough creases.

Refill with tap water any time



Your steam generator iron is designed to use tap water. While ironing, when the water tank runs out of water, you can easily refill it without having to wait or turn off your appliance.

Steam ready in 2 minutes



Steam is ready to use in 2 minutes and can be refilled at any time during ironing.

Automatic shut-off



The auto-off function automatically switches off the appliance if it has not been used for a few minutes, also saving energy.

Easy De-calc



Ultra-long-lasting steam performance: Philips' exclusive Easy De-Calc function provides the ideal way to get rid of limescale and extend the lifetime of your steam generator iron. Your iron will remind you to de-calc with light and sound. When your appliance is cold, simply open the Easy De-Calc knob and collect the dirty water and limescale in a cup.

Safety carry lock



Your steam generator iron comes with a safety carry lock. You can lock your iron safely on the base, making it safer and reducing the risk of people touching the hot soleplate. You can also carry the steam generator easily.



Steam generator iron
6 bar 320 g steam boost, Carry lock, 2.5-l fixed water tank

GC8643/30

Specifications

Calc management

- Calc clean reminder
- Suitable for tap water
- Calc clean solution: Easy De-calc

Technical specifications

- Voltage: 220–240 V

Easy to use

- Safe for all fabrics: Even for delicates such as silks
- Filling and emptying water: Extra-large filling hole
- Water tank capacity: 2500 ml
- Heat-up time: 2 min
- Refill any time
- Safety auto off
- Storage solution: Carry lock

- Cord freedom (swivel): 180 degree cord freedom
- Cord storage: Cord clip
- Power cord length: 1.8 m
- Hose length: 1.7 m
- Hose storage: Hose storage compartment

Fast and powerful crease removal

- Soleplate: T-ionicGlide
- OptimalTEMP technology
- Power: 2400 W
- Pressure: Up to 6 bar pressure
- Safe rest
- Steam boost: 320 g
- Vertical steaming
- Steam tip
- Variable steam settings



Issue date 2023-10-10

Version: 1.0.1

EAN: 87 10103 75414 5

© 2023 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com