

PHILIPS

Beard & stubble trimmer
w/stainless steel blades

Beardtrimmer series
3000

Lift & trim system guides hair

10 settings from 0.5 to 10 mm

45 min cordless use/10 hr
charge

Dry use only



BT3206/13

3-day beard made easy

Lift & Trim system cuts 30% faster*

This trimmer with the innovative Lift & Trim system lifts and captures low-lying hairs for efficient, even trimming results. Easily achieve the 3-day stubble, short beard or long beard look you want.

Easy to use

- Simple maintenance
- Easy to grip
- Know when it's time to charge
- Adjusts to different length settings
- Cordless use for up to 45 minutes

Easy even trimming

- Trims evenly and captures low-lying hairs
- Get a perfect but protective trim
- Skin-friendly blades for smooth skin

Built to last

- Warranty for purchase protection

Highlights

Lift & Trim system



Perfect for stubble, the Philips beard trimmer features our new Lift & Trim system, featuring a comb that lifts and guides the hairs to the level of the blades for an even trim.

Self-sharpening blades



The self-sharpening steel blades on the Philips 3000 beard trimmer stay as sharp and effective as on day 1 to deliver a perfect yet protective trim, time after time.

Skin-friendly blades



Designed to prevent scratches and irritation, the blades have rounded tips for smoother skin contact.

Precision Dial - 10 settings



An effective beard trimmer that cuts to the exact length you're after. Just spin the zoom wheel to one of 10 length settings between 0.5 and 10 mm in 1 mm increments.

45 mins cordless use



Don't get tangled up in your stubble trimmer – one 10 hour charge provides up to 45 minutes of grooming time.

Battery indicators

The green light on the adapter lets you know when your device is charging.

Easy to clean



Detach the head of your Philips beard trimmer and rinse it under the tap for easy cleaning. Then dry it before you put it back on the appliance.

Ergonomic design



A fast trimmer that's comfortable to hold and use. So you can handle those hard-to-reach areas more easily.

Built to last

All of our grooming products are built to last. They come with a 2-year warranty, never need to be oiled and are compatible with any voltage worldwide.

Specifications

Create the look you want

Number of length settings: 10 integrated length settings

Cutting system

Cutter width: 32 mm

Cutting element: Stainless steel blades

Range of length settings: 0.5 mm up to 10 mm

Precision (size of steps): By 1 mm

Non-scratch teeth: For more comfort

Ease of use

Display: Charging indicator on adapter

Zoom wheel: Easily adjust length settings

Cleaning: Rinseable attachments

Operation: Cordless use

Design

Handle: Ergonomic Easy Grip

Accessories

Comb: Lift & Trim system

Maintenance: Cleaning brush

Power

Charging: 10 hours full charge

Automatic voltage: 100-240 V

Battery Type: NiMH

Run time: 45 minutes

Service

2 year guarantee

No oil needed

