



**Saeco Minuto
Super-automatic
espresso machine**

- Brews 7 coffee varieties
- Classic Milk Frother
- Black
- 5 step adjustable grinder



HD8761/01

Always your favorite coffee at just one touch

With the one-click removable brewing group

Only the Saeco Minuto super-automatic espresso machine delivers the real first bean to cup experience with maximum convenience, top-notch performance and large capacities in extra compact dimensions

Advanced technology designed for coffee perfection

- Velvety milk foam with the Classic Milk Frother

High comfort is part of the experience

- The fully removable brewing group can be cleaned in no time

Advanced technology designed for coffee perfection

- 20,000 cups of finest coffee with durable ceramic grinders
- Fine-tune the coffee's richness with 5 grinder settings

 **Saeco**



Highlights

5-steps adjustable grinders



When it comes to the fineness of the grind, this machine never fails to satisfy. Different coffee blends require different levels of granularity for the full flavor to unfold. So the grind granularity of this machine has five adjustable settings - from the finest grind for a full-bodied espresso, to the coarsest for a lighter coffee.

100% Ceramic grinders



Our grinders are made of high-tech ceramic: exceptionally hard and precise. Fresh beans are gently ground, without risk of overheating: extracting all the best flavors and aroma, delivering a superior coffee taste for at least 20,000 cups.

Removable brewing group



Efficiency and ease of use were key inspirations when Saeco invented the first brewing group

30 years ago. And to this day, it still proves to be an inspired, resolute piece of technology. As always, it's so simple to clean – just remove it and wash it under the tap for a few seconds, then re-insert it just as easily.

Classic Milk Frother



The Classic Milk Frother is for those who love to assume the role of master craftsman, and it's just easy. Within seconds you can create a rich, silky layer of foam - the crowning glory of your coffee.

Specifications

Country of origin

- Made in: Europe

Weight and dimensions

- Waste container capacity: 15 servings
- Weight: 7.2 kg
- Product dimensions (L x D x H): 215x429x330 mm
- Coffee bean capacity: 250 g
- Dimensions of product (WxDxH): 215 x 429 x 330 mm

Technical specifications

- Capacity bean container: 250 g
- Cord length: 0.8 m
- Voltage: 230 V
- Frequency: 50 Hz
- Brewing time one cup: 45 (espresso) to 100 (long coffee) s
- Capacity waste container: 15 servings
- Capacity water tank: 1.8 L
- Pump pressure: 15 bar
- Max. cup height: 152 mm
- Water boilers: 1

General specifications

- Cups at the same time: 2
- Suitable for: Whole coffee beans, ground coffee powder
- Coffee strength settings: 5
- Ease of cleaning & maintenance: Automatic de-scaling cycle, Removable brewing group, Automatic rinse cycle, Optional Brita water filter
- Customizing per drink: Adjustable coffee strength, Adjustable cup volume
- Grinder settings: 5
- Ease of use and comfort: Removable spout, Removable drip-tray, Display
- One touch variety: 3
- Type of boiler: Quick heat boiler
- Special functions: Ceramic grinder, Pre-brewing,

Manual milk frother Pannarello

- Type of display: LCD
- Coffee drinks: Espresso, Cappuccino, hot water, Cafè Crème, frothed milk, Espresso Macchiato, Latte Macchiato

Design

- Colour: Mat Black
- Color: Black
- Materials and finishing: Plastic

Logistic data

- Pallet number of pieces: 24

Weight and dimensions

- Weight of product: 7.5 kg

Water tank

- Water tank capacity: 1,8 L

Technical data

- Voltage: 230 V
- Power: 1850 W
- Pump Pressure: 15 bar
- Frequency: 50 Hz

Finishing

- Material boiler: Stainless steel (Inox)
- Material of main body: Plastic
- Material drip tray: Stainless steel
- Material water tank: Plastic
- Material of spout: Plastic
- Material panarello: Plastic

Service

- 2-year guarantee

Sustainability

- Power consumption brewing: 1850 W