

PHILIPS
Saeco



SYNTIA

Philips Saeco Syntia
Super-automatic
espresso machine

- Stainless steel
- Cappuccino



HD8838/03

Live the pleasure of Italian espresso at home

Compact and stylish bean-to-cup system

Syntia Cappuccino is the perfect synthesis of compactness, performance, design and high end materials—everything for your Italian espresso and cappuccino enjoyment at a single touch

Grind your favourite coffee beans

- Play with the coffee's richness with our adjustable grinders
- Adjust coffee length, temperature, strength

Enjoy an Italian lifestyle at home

- Compact and stylish
- One touch espresso, long coffee and cappuccino

Easy to clean and maintain

- Always a clean machine thanks to auto-clean and descaling
- Easy cleaning thanks to removable brewing group


Easy to use

- Ergonomic in day to day operation

Easy to use

- Self-explanatory, colour-coded user interface
- Integrated automatic milk function

 **Saeco**



Highlights

Compact and stylish



Compact and stylish, the Syntia coffee machine is designed to delight both your palate and your eyes - the perfect fit for a modern kitchen.

Espresso and cappuccino



Whether you want to enjoy an espresso, a cappuccino or a long coffee, your specialities are accessible at the touch of a button

5-step adjustable grinders



Different coffee blends require different levels of granularity for the full flavour to unfold. The grind granularity of this espresso machine can be adjusted in 5 settings, from the finest grind, for a full-bodied espresso, to the coarsest, for a lighter café crème.

Auto-cleaning and descaling



Saeco designed this espresso machine to automatically clean its coffee circuit with water when starting up or switching off to deliver a great, fresh taste with each cup of coffee. Regular descaling prolongs your espresso machine's life. This machine will not only prompt when descaling is needed, the automated descaling process will start and guide you with clear on-screen messages when you have to intervene. Descaling has never been so easy!

Removable brewing group



The brewing group, a Saeco invention, is the heart of our espresso machines, ensuring automation. The brewing group is, depending on the model, easily accessible from the front or side. It can be removed effortlessly for easy cleaning by rinsing under the tap, ensuring maximum hygiene.

Colour coded user interface

Enjoy direct and clear interaction thanks to the self-explanatory icons display. For maximum convenience the icons are coloured according to the traffic light colours: Red requires action, Yellow means the coffee machine is "busy" (e.g. heating up) and Green is ready to use.

Coffee customisation



Saeco machines offer you the possibility of customising your coffee exactly the way you like it - from the most intense espresso to a mild cup of long coffee.

Ergonomic day to day



Saeco is a synonym for convenience: refilling beans or water, emptying the coffee-dump box or the drip tray, all compartments of the full automatic coffee machine are directly accessible.

Automatic milk function



With the integrated milk frother, all you have to do is fill it with milk and simply press the cappuccino button. Your drink will be served within seconds as creamy, frothy milk will be poured automatically into your beverage.

Specifications

Easy to use

- Usage: Adjustable coffee dispenser, Bypass for grinded coffee, Frontal access to all functions, Rapid steam, Removable brewing group, Removable water tank
- Cleaning and maintenance: Automatic coffee circuit rinse

Weight and dimensions

- Coffee bean capacity: 250 g
- Product dimensions (L x D x H): 330 x 450 x 415 mm
- Waste container capacity: 8 serv
- Water tank capacity: 1.2 L

Technical specifications

- Boiler material: Stainless steel (Inox)
- Supported coffee types: Ground coffee, Whole

- coffee beans
- Number of water boilers: 1 boiler

Perfect Espresso

- Espresso technology: Saeco adapting system, Aroma-system: pre-brewing

Multi-Beverage

- Milk Variations: Integrated auto milk function

Service

- 2-year worldwide guarantee

Technical data

- Power: 1400 W
- Voltage: 240 V
- Pump Pressure: 15 bar
- Frequency: 50 Hz



Issue date 2022-06-21

Version: 1.1.1

© 2022 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com