



Philips Hairclipper series
5000
Hair clipper

Titanium Blades

21 length settings
60 mins' cordless use/1 hr charge

QC5370/15

Ultimate Control

Style your hair with greater control with this Philips hair clipper. Turn the wheel to select the exact length you want with ease. Get maximum precision with 21 length settings to choose from, ranging from 0.5 mm to 21 mm.

Easy to use

- Contour-following comb follows every curve of your head.
- 2-year guarantee, worldwide voltage, no oil needed
- Shows the battery status
- Up to 60 minutes of cordless power after a 1-hour charge
- Easy but thorough cleaning

Performance

- Superior cutting performance with titanium-coated blades

Ultimate Control

- Easy to select and lock in 21 length settings - 0.5 to 21 mm.

PHILIPS

Highlights

Titanium blades



Advanced titanium blades for superior cutting performance and long-lasting sharpness

Built to last



All of our grooming products are built to last. They come with a 2-year worldwide guarantee and worldwide voltage compatibility, and they never need to be oiled.

100% waterproof



The 100% waterproof beard trimmer, simply rinse it under the tap for a thorough, easy clean.

Follows every curve



The hair clipper gently follows the contours of your head for a fast, even and comfortable haircut.

Zoom wheel length settings



Turn the zoom wheel to select and lock in the length setting you want. The single adjustable comb provides length settings from 3 mm to 21 mm, with precisely 1 mm between each length. Or you can use it without a comb for a close 0.5 mm trim.

Battery light



The light is continuously lit to indicate a full battery, and blinks orange when you have about 10 minutes of usage left.

NiMH batteries



Use with or without the cord for flexibility. The powerful NiMH batteries last for up to 60 minutes after a 1 hour charge. A quick 10 minute charge gives you 10 minutes of clipping time, so it's always ready when you are.

Specifications

Power system

- Battery type: Ni-MH
- Running time: up to 60 minutes
- Charging time: 1 hour

Accessories

- Cleaning brush

Design

- Easy grip: Side panels
- Shape: Ergonomic

Service

- 2-year worldwide guarantee

Cutting system

- Cutter width: 41 mm
- Number of length settings: 21
- Maintenance free - No Oil needed
- Range of length settings: 0.5-21 mm
- Precision (size of steps): by 1 mm
- Cutter material: Stainless steel with titanium coating

Ease of use

- Display: Charging indicator
- 100% Washable: Clean under tap
- Expert 2D comb



Issue date 2024-02-16

Version: 4.0.1

EAN: 87 10103 59733 9

© 2024 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com