



### SENSEO® Viva Café Coffee pod machine

- Adjustable metal spout
- Deep Black
- Direct start



HD7825/60

## Delicious coffee at the touch of a button

### Adjustable metal spout to fit your favourite cup

Enrich your coffee moments with SENSEO® Viva Café coffee machine. The wide range of features, like the choice to make one or two cups of coffee at the same time, adjustable real metal spout and direct start, ensure the ultimate convenience.

#### **Always a delicious cup of coffee**

- Delicious coffee crema layer as proof of SENSEO® quality
- Tested >10,000 times to ensure consistent quality
- Unique brewing system for optimal taste and temperature

#### **Fast and easy operation**

- The only coffee pod maker that brews two cups at a time
- 30-minute auto shut-off for energy saving and safety
- The decalcifying light reminds you when to descale
- Direct Start makes your coffee when the machine is heated up
- Adjust the coffee spout to fit your favourite cup or mug

#### **Coffee variety for every moment**

- Vast variety of SENSEO® coffee blends and flavours



\* Based on retail sales volumes

*Senseo®*

**PHILIPS**

# Highlights

## Delicious coffee crema layer



The fine SENSEO® coffee selection and the unique SENSEO® brewing system make sure that your perfect cup of coffee always comes with a rich and delicious coffee foam layer - proof of premium taste and quality.

## Decalcification indicator



The SENSEO® coffee maker reminds you when to descale. Descale with SENSEO® Descale every 3 months to keep your appliance limescale free; ensuring: maximal in-cup volume; perfect coffee temperature, and; the appliance's durability. Do not use vinegar, as it might damage your SENSEO® appliance and affects the coffee taste.

## Adjustable real metal spout



Adjust the spout's position to fit your favourite cup or mug

## Variety of blends and flavours



SENSEO® has a vast variety of different coffee blends and flavours. Each blend has its own distinctive taste to fit your personal preference.

## 1 or 2 cups at the same time



Prepare 1 or 2 cups of your delicious SENSEO® coffee in less than a minute.

## Automatic shut-off



The SENSEO® coffee maker automatically shuts off after 30 minutes after making coffee, for energy cost saving and appliance safety.

## Machine is tested >10,000 times



Philips tests its coffee makers during the development process with more than 10,000 cups of coffee. This ensures high quality and durability

## Unique brewing system

At SENSEO® we know how to get the best out of the coffee bean to make great tasting single-serve coffee. The operation of the SENSEO® system is simple and brilliant. Water is pumped from the boiler to the coffee pad. The hot water releases the aroma from the pad and gives a perfect cup of coffee. SENSEO® always offers you quality that you can taste.

## Direct start

When pressing the 1 or 2 cup button, while the appliance is heating-up, SENSEO® automatically starts brewing your delicious SENSEO® coffee.

# Specifications

## Country of origin

- Made in: Poland

## Weight and dimensions

- Dimensions of packaging (W x D x H): 232 x 370 x 380 mm
- Weight incl. packaging: 2.4 kg
- Dimensions of product (W x D x H): 190 x 310 x 340 mm

## Technical specifications

- Cord length: 0.8 m
- Voltage: 220 - 240 V
- Frequency: 50 Hz
- Brewing time one cup: 30 sec
- Capacity water tank: 0.9 L
- Pump pressure: 1 bar
- Capacity water tank: Up to 6 cups
- Max. cup height: 100 - 120 mm
- Water boilers: 1
- Brewing time two cups: < 60 sec

## General specifications

- Suitable for: SENSEO® Coffee pods
- Cups at the same time: 2
- Ease of cleaning and maintenance: Descale

- indicator, Dishwasher-safe parts
- Customise each drink: Memo function cup volume
- Ease of use and comfort: Removable drip tray, Removable spout, Brew stop, Direct start, Automatic shut-off, Removable water tank
- Coffee drinks: Café Crème

## Weight and dimensions

- Weight of product: 1.75 kg

## Finishing

- Material of main body: Plastic
- Material boiler: Metal and glass-filled polyamide
- Material drip tray: Metal
- Material water tank: Plastic
- Material of spout: Stainless steel

## Service

- 2 year guarantee

## Sustainability

- Sustainability certification: Green tick
- Power consumption stand-by: 0.36 W
- Power consumption brewing: 1450 W
- Made of recycled materials: 90% (paperwork and packaging)