



Philips Aluminium
Collection
Coffee maker

- With glass jug
- Boil and brew system
- Aluminium

HD5410/00

Fantastic taste and rich aroma

Superior Coffee Boil & Brew system

This elegant coffeemaker allows you to enjoy a rich aroma and full flavor thanks to its unique Boil & Brew system

Superior aroma

- Boil & Brew system for ultimate aroma and taste
- Aroma jug

Ultimate Convenience

- Cable storage
- Dishwasher-proof parts for easy and convenient cleaning
- Automatic shut-off after 1 hour
- Drip stop

PHILIPS

Coffee maker
With glass jug Boil and brew system, Aluminium

HD5410/00

Highlights

Boil & Brew



The Philips coffeemaker has a unique Boil & Brew system. Water is boiled first and then flows through ground coffee. Thanks to high brewing temperature reaching 93°C or higher, this ensures the richest flavor and superior aroma for your filter coffee.

Aroma jug



For 8-12 cups, designed to optimally preserve the coffee flavour.

Drip Stop



Drip stop to interrupt brewing whenever you want to pour a cup of coffee

Auto shut-off after 1 hour



1 hour after brewing coffee, the coffee machine will shut-off automatically and save energy.

Cord storage



Storing the cable under the coffeemaker will avoid cable clutter for a clean kitchen work top.

Dishwasher-proof parts



Dishwasher-proof parts for easy and convenient cleaning.

Specifications

Technical specifications

- Power: 1250 W
- Voltage: 220-240 V
- Supported coffee types: Ground coffee
- Cord length: 1.0 m
- Frequency: 50/60 Hz
- Capacity: 1.1/ 8 - 12 cups Litres / cups
- Brewing time: 11 minute(s)

Accessories

- Included: Glass jug
- Jug

Design specifications

- Color(s): Aluminium
- Dimensions (L x W x H): 210 x 210 x 490 mm
- Bowl, cover, pusher
- Weight appliance: 2.3 kg
- Weight (incl. packaging): 3.0 kg

Ultimate taste and aroma

- Boil and brew system

Good filter coffee made easily

- Water level indication



Issue date 2022-06-22

Version: 1.1.1

© 2022 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com