



Philips Saeco Royal
Super-automatic
espresso machine

- Royal
- One Touch
- Cappuccino

HD8930/04

So simple, so delicious

With large capacities and insulated milk container

The new Saeco Royal HD8930/01 is the rejuvenation of a trusted classic. What remains unchanged is the extremely solid performance and the generous tanks for beans, water and coffee grounds.

Ease of cleaning and maintaining

- Always a clean machine thanks to auto-clean and descaling

Easy to use

- Ergonomic in day-by-day operations

Easy to use

- Cup warmer
- Insulated milk container
- One touch beverage selection


Ease of cleaning and maintaining

- Dishwasher safe Cappuccinatore
- Easy cleaning stainless steel milk container

Coffee specialty customization

- Adjustable coffee length and intensity

 **Saeco**



Highlights

Adjustable coffee length and



Choose your favorite coffee blend and adjust coffee length and intensity (temperature, pre-brewing, strength). Length: you can adjust the amount of brewed coffee according to your taste and/or the size of your cups.

Temperature: the machine allows you to adjust via setting menu the temperature of your coffee. Pre-brewing: you can adjust via setting menu the time of pre-wetting of the coffee powder into the infusion chamber, in order to extract all the taste. Strength: the machine is set-up for adjusting the strength with the amount of coffee to be ground, using the specific lever on the side.

Auto cleaning and descaling



Saeco designed this espresso machine to automatically clean its coffee circuit with water upon starting up or switching off of the machine, this delivers a great, fresh taste with each cup of coffee. Regular descaling prolongs your espresso machine's life. This machine will not only prompt when descaling is needed, the automated descaling process will start on your machine and guides you with clear on-screen messages when you have to intervene. Descaling has never been so easy!

Cup warmer



This feature allows you to not only store your espresso cups and glasses right on the espresso machine, it also pre-heats them letting the aroma unfold even better and guaranteeing a long-lasting crema

Dishwasher safe Cappuccinatore



Keep the Saeco espresso machine at its best, by cleaning the automatic Cappuccinatore simply washing it with lukewarm water or directly into the dishwasher machine.

Professional double boiler



With 2 separate heating systems to cater for both the optimal coffee or milk frothing temperatures, this Saeco fully automatic

espresso machine guarantees professional performance and speed everytime. You are able to prepare as many latte macchiatos and cappuccinos as you wish, one after the other and each just as good as the previous without waiting.

Easy cleaning milk container



The milk container has been designed in order to be easy to dismantle and with premium materials (stainless steel). The cleaning is quick and simple and can be done everyday without efforts, for a perfect cleaning of the milk system.

Ergonomic day-by-day



Saeco is a synonym for convenience: refilling beans or water, emptying the coffee-dump box or the drip tray, all compartments of the full automatic coffee machine are directly accessible.

Specifications

Easy to use

- Cleaning and maintenance: Automatic milk circuit rinse, Descaling cycle
- Usage: Adjustable coffee dispenser, Instant steam (2 boilers), Removable brewing group

Weight and dimensions

- Product dimensions (L x D x H): 336 x 380 x 450 mm
- Waste container capacity: 20 servings
- Coffee bean capacity: 350 g
- Product weight: 15 kg
- Milk carafe capacity: 0,5 L
- Water tank capacity: 2.2 L

Technical specifications

- Voltage: 220 V
- Cord length: 80 cm
- Power: 1400 W
- Supported coffee types: Ground coffee, Whole coffee beans
- Boiler material: Stainless steel (Inox)
- Frequency: 50 Hz

- Country of origin: Designed in Italy, Made in Italy
- Water pressure in pump: 15 bar (perfect espresso)
- Number of water boilers: 2 boilers (instant steam)
- Removable brewing group

Features

- Simultaneous brewing
- Hot water wand

Perfect Espresso

- Espresso technology: Aroma-system: pre-brewing, Cup warmer

Design

- Colour: Glossy Silver
- Materials and finishing: Plastic Front/Top + Metal sides/rear

Service

- 2-year worldwide guarantee

Sustainability

- Automatic Stand-by Option



Issue date 2022-06-23

Version: 1.1.1

© 2022 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com