

Philips PowerPro Active  
Bagless vacuum cleaner

**2000W**

PowerCyclone 4  
HEPA 10 washable filter

**FC8631/61**



## Always the highest suction power\*

### With PowerCyclone 4 Technology

The new Philips PowerPro Active delivers outstanding cleaning results thanks to the PowerCyclone 4 technology. The advanced dust container is easy to empty and helps avoiding dust clouds.

#### **Easy to clean**

- Advanced dust container design for easy emptying

#### **Clean air in your home**

- The EPA filter catches microscopic vermin causing allergy

#### **Ergonomic grip for far reach**

- Reach all corners thanks to the extra long ergonomic grip

#### **Powerful cleaning performance**

- PowerCyclone 4 technology separates dust and air in one go
- 2000 Watt motor for high performance

# PHILIPS

# Highlights

## PowerCyclone 4 Technology



PowerCyclone 4 technology maximizes airflow and performance by separating dirt from air in one go. It delivers remarkable cleaning results through highly efficient steps: 1) Air enters fast into the PowerCyclone thanks to the straight and smooth air inlet. 2) The curved airpass quickly accelerates the air upwards in the cyclonic chamber to separate the dust from the air.

## 2000 Watt motor



The 2000 Watt motor generates max. 370 Watt suction power for high performance.

## EPA filter system

The pleated EPA filter has a large filter surface and good filtration performance. In combination with the

cyclonic airflow, this prevents it from clogging fast and gives you better and longer-lasting filtration results.

## Easy to empty dust container



The dust container is perfectly designed to dispose dust without creating a dust cloud. Thanks to its unique shape and smooth surface, dust is collected at one side of the container and evenly glides into the dust bin.

## Extra long ergonomic grip



This ergonomically shaped grip is convenient in use. Its extra long design gives you farther reach, so you can easily clean hard to reach places.

# Specifications

## Design

- Color: Deep black

## Performance

- Input power (max): 2000 W
- Input power (IEC): 1800 W
- Noise level (Lc IEC): 80 dB
- Suction power (max): 370 W
- Vacuum (max): 30 kPa
- Airflow (max): 35 l/s

## Usability

- Action radius: 9 m
- Tube coupling: Conical
- Cord length: 6 m
- Carrying handle: Top and front
- Tube type: Aluminum telescopic tube
- Power control: Electronic on appliance
- Wheel type: Rubber

## Nozzles and accessories

- Accessories included: Crevice tool, Small nozzle
- Standard nozzle: Multi-purpose nozzle
- Accessory storage: On tubeclip

## Weight and dimensions

- Dimensions of product (LxWxH): 473x304x301 mm
- Weight of product: 6 kg

## Sustainability

- Packaging: > 90% recycled materials
- User manual: 100% recycled paper

## Filtration

- Dust capacity: 1.7 L
- Exhaust filter: Microfilter
- Motor filter: EPA 10 washable filter



Issue date 2022-06-24

Version: 1.1.2

© 2022 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)

\* Suction power results compared to Philips PowerPro Compact FC8470, tested internally January 2013.