



Philips Saeco Intelia
Super-automatic
espresso machine

- Automatic Milk Frother
- Stainless steel

HD8752/25

One touch espresso and milk froth

With Saeco's ultimate cappuccinatore

Only the Saeco Intelia super-automatic espresso machine offers you the perfect Espresso experience, easy to use, easy to customize, easy to clean. Prepare a tasty Espresso or creamy milk froth with just a touch of a button.

Authentic Italian coffee perfection

- Coffee without burnt taste thanks to 100% ceramic grinders
- Delicious milk froth thanks to the automatic milk frother
- Coffee without waiting thanks to the quick heat boiler

Ease of cleaning and maintaining

- Always a clean machine thanks to auto-clean and descaling
- Easy cleaning thanks to removable brewing group

Ease of cleaning and maintaining

- Easy cleaning thanks to dishwasher-safe parts
- Cutting-edge design with stainless steel finish

Set the beverages to suit your taste

- Save your favorite coffee settings
- Avoid heat loss and fit every cup with our adjustable spout
- Play with the coffee's richness with our adjustable grinders

 **Saeco**



Highlights

Stainless steel



The cutting-edge design of your Saeco espresso machine is rounded off by the stainless steel finish. The stainless steel provides a high quality look and will be a highlight on your kitchen counter tops. It also gives greater resistance for a long-lasting performance.

100% ceramic grinders



This espresso machine is equipped 100% ceramic grinders. Saeco uses ceramic grinders because of their consistent grind without overheating the coffee bean for an impeccable espresso. Ceramic also ensures long-lasting performance and a totally silent operation.

Quick heat boiler



The Saeco quick heat boiler technology ensures your machine is always ready. Now you won't have to wait between brewing each espresso, but can prepare coffee after coffee.

Saves your coffee settings



You will always get a perfect cup of espresso brewed just for you, according to your personal preference, thanks to our innovative memo function to adjust the coffee length, strength and temperature. Enjoy a superb coffee drink in your favorite cup with just the press of a button.

Adjustable spout



The adjustable spout on our espresso machines will fit every cup and thus prevents

the coffee splashing or cooling down while pouring in your cup. This way your espresso is always served at the right temperature while maintaining a clean machine.

Dishwasher-safe parts



For your convenience, you can put the Saeco's drip tray and milk frother or milk carafe in the dishwasher. This will save time and ensure a hygienic cleaning.

5 step adjustable grinders



Different coffee blends require different levels of granularity for the full flavor to unfold. The grind granularity of this espresso machine can be adjusted in 5 settings, from the finest grind, for a full bodied espresso, to the coarsest, for a lighter coffee.

Specifications

Easy to use

- Cleaning and maintenance: Automatic coffee circuit rinse, Descaling cycle
- Usage: Adjustable coffee dispenser, Cup holding surface, Rapid steam, Removable brewing group, Normal / long espresso option

Weight and dimensions

- Product dimensions (L x D x H): 256 x 340 x 440 mm
- Coffee bean capacity: 300 g
- Waste container capacity: 10 servings
- Product weight: 8.9 kg
- Maximum cup height: 130 mm
- Water tank capacity: 1.5 L

Technical specifications

- Cord length: 80 cm
- Supported coffee types: Whole coffee beans, Ground coffee
- Power: 1850 W
- Boiler material: Stainless steel (Inox)
- Country of origin: Made in Europe, Designed in Italy

- Water pressure in pump: 15 bar (perfect espresso)
- Number of water boilers: 1 boiler
- Removable brewing group

Features

- Cappuccinatore
- Brita Filter compatible: Optionable, Yes
- Hot water / Steam Nozzle
- Simultaneous brewing

Design

- Colour: Stainless Steel/Black
- Materials and finishing: Stainless Steel/Plastic

Perfect Espresso

- Espresso technology: Saeco adapting system, Aroma-system: pre-brewing

Service

- 2-year worldwide guarantee

Sustainability

- Automatic Stand-by Option



Issue date 2022-06-25

Version: 1.1.1

EAN: 08 71010 36550 77

© 2022 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com