



Philips Performer
Vacuum cleaner with bag

2000W

500W suction power
HEPA 13 washable filter

FC9172/67

The highest suction power ever

500 Watt suction power for effortless cleaning

The Special Edition Performer celebrates 40 years of Floor Care experience for Philips. We are celebrating this milestone with a unique Titanium color.

Superior cleaning

- 2200 Watt motor generating max. 500 Watt suction power

Highly efficient anti-allergy system

- HEPA AirSeal plus HEPA 13 filter

Highly efficient anti-allergy system

- ECARF Seal of Quality for trusted results

Long lasting dust pickup

- s-bag in XXL 4 liter capacity for long-lasting performance

Easy cleaning, even around furniture

- TriActive nozzle with unique 3-in-1 action

PHILIPS

Highlights

Powerful cleaning



Highly efficient 2200 Watt motor generates max. 500 Watt suction power for perfect cleaning results.

HEPA AirSeal, HEPA 13 filter



This Philips vacuum cleaner has been designed in such a way that all the air taken in is passed through the washable HEPA 13 filter (99.95% filtration) before it is exhausted. No escape is possible.

s-bag in XXL 4 liter



This large dust bag capacity allows you to make optimal use of your dust bag, which means you have to change your dust bag less frequently.



TriActive nozzle



The TriActive nozzle cleans your floor in 3 ways in one go: 1) A larger opening at the tip of the nozzle easily sucks up big bits. 2) It has maximum cleaning efficiency due to optimized airflow through the nozzle. 3) The two side brushes sweep up the dust and dirt closely alongside furniture and walls.

ECARF Seal of Quality Award



This ECARF certified vacuum cleaner guarantees with 99.95% certainty that almost all the air in the room will be filtered along with the normal vacuum action. This removes almost all allergens from carpets, furniture, and other spaces in your house.

Specifications

Performance

- Input power (max): 2200 W
- Input power (IEC): 2000 W
- Noise level (Lc IEC): 78 dB
- Suction power (max): 500 W
- Vacuum (max): 34 kPa
- Airflow (max): 47 l/s

Design

- Color: Titanium

Usability

- Action radius: 12 m
- Tube coupling: Easy release
- Cord length: 7 m
- Carrying handle: Top and front
- Power control: Electronic on appliance
- Tube type: Metal 2-piece telescopic tube
- Wheel type: Rubber
- Dust full indicator
- Clean Comfort cassette

Nozzles and accessories

- Standard nozzle: TriActive nozzle
- Accessories included: Brush, Crevice tool, Small nozzle
- Accessory storage: On handgrip

Weight and dimensions

- Dimensions of product (LxWxH): 500 x 320 x 280 mm
- Weight of product: 6.3 kg

Filtration

- Dust capacity: 4 L
- Dust bag type: s-bag
- Exhaust filter: Ultra Clean Air HEPA 13 washable filter
- HEPA Air Seal



Issue date 2023-04-14

Version: 1.1.1

EAN: 87 10103 61600 9

© 2023 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com