

Philips Performer
Vacuum cleaner with bag

2200W

500W suction power
HEPA 13 filter

FC9160/01



The highest suction power ever

500 Watt suction power for effortless cleaning

The highest suction power ever, resulting in effortless cleaning: this is what the Philips Performer is all about. Combined with a hygienic filter and easy dustbag removal system the Performer takes care of all your dust and dirt.

Superior cleaning

- 2200 Watt motor generating max. 500 Watt suction power

Highly efficient anti-allergy system

- ECARF Seal of Quality for trusted results

Long lasting dust pickup

- s-bag in XXL 4 liter capacity for long-lasting performance

Easy cleaning, even around furniture

- TriActive nozzle with unique 3-in-1 action

Traps dust and allergens inside

- Ultra Clean Air HEPA 13 filter, 99.95% filtration

PHILIPS

Highlights

Powerful cleaning



Highly efficient 2200 Watt motor generates max. 500 Watt suction power for perfect cleaning results.

s-bag in XXL 4 liter



This large dust bag capacity allows you to make optimal use of your dust bag, which means you have to change your dust bag less frequently.

TriActive nozzle



The TriActive nozzle cleans your floor in 3 ways in one go: 1) A larger opening at the tip of the nozzle



easily sucks up big bits. 2) It has maximum cleaning efficiency due to optimized airflow through the nozzle. 3) The two side brushes sweep up the dust and dirt closely alongside furniture and walls.

ECARF Seal of Quality Award



This ECARF certified vacuum cleaner guarantees with 99.95% certainty that almost all the air in the room will be filtered along with the normal vacuum action. This removes almost all allergens from carpets, furniture, and other spaces in your house.

Ultra Clean Air HEPA 13, 99.95% filtration



Ultra Clean Air HEPA 13 filter, 99.95% filtration

Specifications

Performance

- Input power (max): 2200 W
- Input power (IEC): 2000 W
- Noise level (Lc IEC): 78 dB
- Suction power (max): 500 W
- Vacuum (max): 34 kPa
- Airflow (max): 47 l/s

Design

- Color: Dark denim

Usability

- Cord length: 9 m
- Action radius: 12 m
- Tube coupling: Button
- Carrying handle: Top and front
- Tube type: Metal lacquered 2-piece telescopic tube
- Power control: Electronic on appliance
- Dust full indicator
- Wheel type: Rubber
- Clean Comfort cassette

Nozzles and accessories

- Standard nozzle: TriActive nozzle
- Accessories included: Crevice tool, Small nozzle
- Accessory storage: On handgrip

Weight and dimensions

- Dimensions of product (LxWxH): 500 x 320 x 280 mm
- Weight of product: 6.3 kg

Filtration

- Dust capacity: 4 L
- Dust bag type: s-bag
- Exhaust filter: Ultra Clean Air HEPA 13 filter



Issue date 2023-04-14

Version: 1.1.1

© 2023 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com