



Philips
Pressurised steam
generator

GC8220

Great results, minimum effort

Endless, powerful steam with 1.4 liter water tank

Powerful yet surprisingly compact, this ironing system produces non-stop high steam with high pressure, making ironing fast and easy. Thanks to the 1.4 liter detachable water tank, you can iron for hours without interruption.

Fast and powerful ironing

- Up to 4.5 bars of steam pressure for fast ironing
- Continuous steam up to 110 g/min
- Ready to use in 2 minutes with unlimited refill
- 120 g steam boost to remove stubborn creases easily

Comfortable ironing

- Lightweight iron for effortless ironing

Reaches into tricky areas

- Steam tip lets you iron right into hard-to-reach areas

Smooth gliding

- SteamGlide soleplate for powerful steam and superb gliding

Iron up to 3 hours without refilling

- Xtra large detachable 1.4 liter water tank

PHILIPS

Highlights

Detachable water tank



To make ironing effortless you need a lot of steam. High steam output means a lot of refilling. The extra large 1.4 l water tank reduces the need of refilling.

Up to 4.5 bar



Double your ironing speed with pressurized steam. Pressurized steam penetrates deep into fabrics, making your ironing fast and easy, even on difficult fabrics.

Steam tip

The unique steam tip combines a particularly pointed front of the soleplate with special steam slots in the tip to reach right into the smallest and most difficult areas for the best ironing results.

Lightweight

The iron is only 1.2 kg making ironing easy and effortless.

Continuous steam



The more steam, the faster the ironing. The unique technology in a Philips steam generator iron generates powerful steam making ironing easier, better and faster.

Steam boost up to 120 g



The iron's 120 g steam boost enables you to easily remove even the most stubborn creases.

Steam ready in 2 minutes



Steam is ready to use in 2min and can be refilled at anytime during ironing.

SteamGlide Soleplate



This specially designed soleplate combines superior ceramic coating for superior gliding on all fabrics and carefully designed vents for powerful crease removal.

Specifications

Technical specifications

- Frequency: 50-60
- Voltage: 220 - 240
- Boiler wattage: 1200
- Iron wattage: 800

Weight and dimensions

- Product weight: 6,06
- Product dimensions: 350 x 350 x 250

Easy to use

- Control: Temperature ready light, Variable steam settings
- Reaching tricky areas: Button groove, Steam tip
- Easy to set up and store: Easy cord and hose storage, Extra-large water inlet
- Water tank: Crystal clear

Smooth gliding

- Soleplate: SteamGlide soleplate

Comfortable ironing

- Cord length: 2,5 m
- Additional comfort: Steam trigger lock
- Anti-scale management: Easy Rinse
- Hose length: 1,9, 1.9 m
- Safe in use: Overheat safety stop
- Suitable for tap water

Crease removal

- Vertical Steam: Continuous vertical steam
- Soleplate: Optimal vent pattern



Issue date 2024-02-20

Version: 1.1.1

EAN: 87 10103 31520 9

© 2024 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com