

Philips Pure Essentials
Collection
Food processor

1000 W

Compact 2 in 1 setup
3.4 L bowl

HR7774/30



Effortless excellence

Powerful food processor with bigger tube and bowl

This state-of-the-art food Philips processor has some of the most advanced technologies. Its versatility is ensured by 7 accessories which easily perform 30+ functions.

Effortlessly easy

- One touch (dis)assembly
- XL feeding tube takes whole fruits or vegetables
- 7 accessories to easily perform 30+ functions
- Up to 7 portions in 1 go with the XL bowl

Powerful precision

- 1000 W motor
- Adjustable blade for slices between 1-7 mm
- Ice and pulse functions for chopping and crushing

Reliably durable

- Dishwasher safe accessories

Stylishly compact

- Compact 2-in-1 setup saves countertop space

PHILIPS

Food processor
1000 W Compact 2 in 1 setup, 3.4 L bowl

Highlights

30+ functions



The – dishwasher safe - accessories are a kneading tool for mixing batter and for heavy kneading. A stainless steel chopping knife to prepare meat and vegetables. Two metal disks to handle medium and fine shredding and grating. Break resistant blender of 1.5l for blending, crushing up to stirring different ingredients. A citrus press for pressing citrus fruits. And a balloon beater for whipping and whisking and handling light batter.

Adjustable slicing blade

With the adjustable slicing blade, you can make slices as thin as 1 mm and up to 7 mm thick.

1000 W motor

With the powerful 1000 W motor of this Philips food processor you can adjust speed precisely to get desired results.

XL feeding tube



The XL feeding tube takes whole fruits and vegetables so you don't need to pre-cut them anymore.

XL 3.4 L bowl



The XL bowl allows for maximum volumes to be processed in one go: capacity for 2 l soup, 1.7 kg dough, 7 eggwhites.

Compact 2-in-1 setup



Compact setup fits blender or bowl to save countertop space

Dishwasher safe accessories



Dishwasher safe accessories

Ice and pulse functions

Ice and pulse functions for chopping and crushing

One touch (dis)assembly

One touch (dis)assembly

HR7774/30

Specifications

Country of origin

- China

Technical specifications

- Cord length: 120 cm
- Power: 1000 W
- Voltage: 220-240 V
- Blender jar capacity: 1.5 L
- Frequency: 50-60 Hz
- Bowl capacity dough: 1700 g
- Bowl capacity dry: 3.4 L
- Speeds: Variospeed
- Safety: Lid & bowl detection, mechanical 1.5 sec brake
- Bowl capacity flour: 1000 g
- Bowl capacity liquid: 2 L

General specifications

- Non-slip feet

Accessories

- Kneading tool: For kneading, heavy kneading, mixing dough, batter
- Balloon beater: Double beater for whipping, whisking, mixing and emulsifying
- Stainless steel chopping knife: chopping, Beating, creaming, crumbling, cutting, folding in, mashing, mincing
- Citrus press: For pressing of citrus fruits
- Recipe book
- Number of inserts/disks: 2
- Reversible shredding disk: For medium and fine shredding
- Adjustable slicing disk: For 1-7 mm slices of fruit & vegetables
- Break resistant blender: blending, crushing, foaming, grinding, pureeing, homogenizing, liquidizing, milling, shaking, stirring

Design specifications

- Color(s): White
- Housing: ABS
- Speed knob: Brushed aluminium
- Bowl including lid and blender: SAN
- Disks, chopping blade: Stainless steel
- Function buttons: Pulse, Ice
- Kneading tool, citrus press: PP
- Pusher, inner pusher: ABS, SAN
- Knife holder, balloon beater: POM

General specifications

- Integrated cord storage



Issue date 2022-06-29

Version: 1.1.1

© 2022 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com