

Philips Daily Collection
Food processor

650W

2 speeds + pulse
2.1 L bowl
Accessories for + 15 functions

HR7627/01



Maximum variety of recipes, minimum effort

Create home made breads, cakes, drinks and more

This Philips Daily collection Food Processor has a compact design including a 2.1L bowl and a variety of high performance accessories. Preparing delicious homemade food has never been so easy!

Easiest assembly, use and cleaning

- 2 speed settings and pulse for maximum control
- 40% larger feeding tube (compared to Philips HR7625)
- 650 Watt motor for powerful processing
- Dishwasher safe accessories
- No mess from center of the bowl due to lack of inner shaft

Maximum variety of recipes

- Emulsifying tool for cream and egg whites
- Sharp and strong stainless steel S blade for chopping
- Up to 5 portions in one go
- High performance stainless steel disc inserts

Powerful precision

- PowerChop technology for superior chopping performance

PHILIPS

Food processor
650W 2 speeds + pulse, 2.1 L bowl, Accessories for + 15 functions

HR7627/01

Highlights

2 speed settings and pulse



For best results, use the low speed setting (speed 1) to whip cream, beat eggs, create pastries and bread dough. The higher speed setting (speed 2) is well suited to chop onions and meats, blend soups and smoothies or shred, slice, grate or rasp vegetables.

40% larger feeding tube



The new Philips Daily collection Food Processor comes with a feeding tube which is 40% larger than the previous HR7625 model, saving precutting time of fruits and vegetables

Powerful processing

650W

This Philips Food Processor offers a powerful motor providing power and control to prepare all your favorite recipes.

Up to 5 portions in one go



The generous 2.1L bowl (1.5 L working capacity) enables you to blend up to 5 portions of soup in one go.

Dishwasher safe accessories



All accessory parts of your Philips food processor can be put on the top rack of your dishwasher for easy cleaning.

Emulsifying tool



The perfect tool for whipping, whisking or emulsifying eggs or whipped cream. For best volume increase and fluffiness, use the low speed setting. Creating delicious desserts or mayonnaise has never been easier!

Stainless steel disc inserts



Simply select the right stainless steel disc insert to prepare your favorite ingredient and click it onto the disc holder. Performance has been tested extensively to provide the best slicing and shredding results.

PowerChop technology



PowerChop

PowerChop technology is a combination of blade shape, cutting angle and inner bowl that provides a superior chopping result in both soft and hard ingredients. It is also perfect for making purées and mixing your cake batters!

Specifications

General specifications

- Speeds: 2 + pulse
- Non-slip feet
- Integrated cord storage
- Product size (LxVxH): 244x244x377 mm
- RPM-Bowl(max): Up to 1900 rpm
- RPM-Bowl(min): Up to 1500 rpm
- Bowl max working capacity: 1.5L (dry/liquid)
- Bowl capacity: 2.1 L
- Bowl max working capacity.: 500g (Flour)

Accessories

- Emulsifying disk
- Kneading tool
- Stainless steel chopping knife: Beating, chopping, crumbling, cutting, folding in, mashing, mincing
- Stainless steel S-blade
- Disc insert: granulating
- Disc insert: shredding(coarse)
- Number of inserts/discs: 3
- Disc insert: slicing(fine)

Design specifications

- Housing: ABS
- Bowl including lid: SAN
- Disc inserts, chopping knife: Stainless steel
- Kneading tool: PP
- Knife holder: PP
- Pusher: SAN
- Speed knob: ABS

Technical specifications

- Power: 650 W
- Voltage: 220-240 V
- Frequency: 50/60 Hz
- Safety: Lid & bowl detection, mechanical 1.5 sec brake

Consumer Trade Item

- Height: 27.5
- Width: 25.5
- Length: 34.5
- Net Weight: 2.3
- Gross Weight: 3.15
- GTIN: 08710103590774
- Country of origin: CN
- Harmonized system code: 850940

Outer Carton

- Height: 36
- Width: 29
- Length: 52.5
- Gross Weight: 6.53
- GTIN: 18710103590771

Other

- Height: 193
- Width: 80
- Length: 120
- GTIN: 68710103590776



Issue date 2023-03-18

Version: 1.1.2

EAN: 87 10103 59077 4

© 2023 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com