

Philips Jewel
Vacuum cleaner with bag

2000 W

HEPA 13 filter
3L

FC9071/01



Beautiful results in the blink of an eye

TriActive nozzle with unique 3-in-1 action

The Jewel vacuum cleaner range with bag is ideal for those who want beautiful results fast. It comes with the patented TriActive nozzle that gives you three cleaning actions in one stroke.

Highly efficient anti-allergy system

- HEPA AirSeal plus HEPA 13 filter

Easy cleaning, even around furniture

- TriActive nozzle with unique 3-in-1 action

Beautiful floors in a blink of an eye

- 2000 Watt motor generating max. 450 Watt suction power

PHILIPS

Specifications

Performance

- Input power (max): 2000 W
- Input power (IEC): 1800 W
- Noise level (Lc IEC): 76 dB
- Suction power (max): 450 W
- Vacuum (max): 32 kPa
- Airflow (max): 43 l/s

Design

- Colour: Blue bonnet

Usability

- Tube coupling: Button
- Action radius: 10 m
- Cord length: 7 m
- Carrying handle: Front
- Tube type: Metal lacquered 2-piece telescopic tube

- Power control: Electronic on appliance
- Wheel type: Plastic
- Dust full indicator
- Clean Comfort cassette

Nozzles and accessories

- Standard nozzle: TriActive nozzle
- Accessories included: Crevice tool, Small nozzle

Weight and dimensions

- Weight of product: 5.7 kg

Filtration

- Dust bag type: s-bag
- Dust capacity: 3 L
- Exhaust filter: Ultra Clean Air HEPA 13 filter
- HEPA Air Seal

Highlights

2000 Watt motor



The highly efficient 2000 Watt motor generates max. 450 Watt suction power for perfect cleaning results.

HEPA AirSeal, HEPA 13 filter



This Philips vacuum cleaner has been designed in such a way that all the air taken in is passed through the washable HEPA 13 filter (99.95% filtration) before it is exhausted. No escape is possible.

TriActive nozzle



The TriActive nozzle cleans your floor in 3 ways in one go: 1) A larger opening at the tip of the nozzle easily sucks up big bits. 2) It has maximum cleaning efficiency due to optimised airflow through the nozzle. 3) The two side brushes sweep up the dust and dirt closely alongside furniture and walls.



Issue date 2023-04-14

Version: 1.1.1

© 2023 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com