



Philips ClearTouch
Garment Steamer

2000 W

Adjustable pole with hang&lock
Pleat maker, glove

GC534/20

Remove creases in no time

Designed for powerful performance and convenience

The new Philips ClearTouch garment steamer is designed for powerful crease removal in a few strokes. Its contemporary, unique design is accompanied by smart features and powerful steam that will make ironing both easier and faster.

Easy to use

- Adjustable pole
- Easy Rinse descaling function
- Unique Hang&Lock for stability during steaming
- Detachable, transparent water tank with hygienic water inlet

Quick crease removal

- XL Stainless steel steam plate for faster results
- Extra powerful steam

Perfect pleats made easy

- Pleats made easy with pleat making accessory

Maximum safety

- PVC free silicon steam hose
- Safe to use on delicate fabrics, like silk
- Glove for extra protection during steaming

PHILIPS

Highlights

Extra powerful steam



Powerful steam is blown through the nozzles, enabling you to remove creases with only a few strokes.

Adjustable pole



Integrated adjustable pole for hanging your garments while using the steamer. It is collapsible for easy storage.

PVC free silicon steam hose



The steam hose is made of silicon material which is the safe and healthy choice for use with steam. As the safety and health of your family is important, no PVC is used in the steam hose.

XL Stainless steel steam plate



The steamer head has an XL stainless steel steam plate which delivers faster results.

Detachable water tank



1.2 L detachable water tank with special water inlet for extra hygiene.

Safe on all garments



The steamer is safe to use on all fabrics. It is a great solution for delicate fabrics like silk.

Hang&Lock



Unique Hang&Lock feature locks the garment hanger and enables stability for more convenient steaming - even with your own hanger.

Easy Rinse descaling function



Prolong the lifetime of your appliance by using the Easy Rinse descaling function regularly.

Glove for extra protection



Included is a glove that protects your hand during steaming.

Specifications

Easy to use

- Water tank capacity: 1200 ml
- Safe on all ironable fabrics: Even delicates like silk
- Soleplate name: XL steam plate
- Detachable water tank
- Refill any time during use
- Tap water suitable
- Power cord length: 1.6 m
- Silicone steam hose
- Special water inlet: For extra hygiene

Accessories included

- Adjustable pole
- Glove for extra protection
- Pleat maker

Fast crease removal

- Power: 2000 W
- Continuous steam: 40 g/min
- Voltage: 240 V

Scale management

- Descaling and cleaning: Easy Rinse

Size and weight

- Weight of iron: 3.5 kg
- Packaging dimensions (WxHxL): 40x45x33.3 cm
- Product dimensions (WxHxL): 33x172x33 cm
- Total weight with packaging: 5.47 kg

Green efficiency

- User manual: 100% recycled paper



Issue date 2023-01-14

Version: 1.1.1

EAN: 08 71010 36680 77

© 2023 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com