



Saeco Talea  
Super-automatic  
espresso machine

• Silver

R19822/47

# Cafè-enjoyment in elegance awaits you

## Enjoy your espresso

Talea standard line

**Authentic Italian coffee perfection**

- Delicious milk froth thanks to the classic milk frother


**Ease of cleaning and maintaining**

- Always a clean machine thanks to auto-clean and descaling
- Easy cleaning thanks to removable brewing group

**Set the beverages to suit your taste**

- Boost coffee crema and body

 **Saeco**



# Highlights

## Classic milk frother



This Saeco espresso machine comes with the classic milk frother that baristas call a "Pannarello". It dispenses steam and is immersed in milk to prepare gorgeous milk foam. Unleash your inner barista by preparing your delicious milk specialties the traditional way!

## Removable brewing group



The brewing group, a Saeco invention, is the heart of our espresso machines, ensuring automation. The brewing group is, depending on the model, easily accessible from the front or side. It can be removed effortlessly for easily cleaning by rinsing under the tap ensuring maximum hygiene.

## Auto cleaning and descaling



Saeco designed this espresso machine to automatically clean its coffee circuit with water upon starting up or switching off of the machine, this delivers a great, fresh taste with each cup of coffee. Regular descaling prolongs your espresso machine's life. This machine will not only prompt when descaling is needed, the automated descaling process will start on your machine and guides you with clear on-screen messages when you have to intervene. Descaling has never been so easy!

## Crema and body boost



This Saeco features our patented crema and body boost. This dial, conveniently located at your machine's spout, allows you to smoothly adjust the counter pressure changing your espresso's body and crema. Try it yourself and find your favorite taste.

# Specifications

## Perfect Espresso

- Espresso technology: Saeco adapting system, Aroma-system: pre-brewing, SBS: creme adaptor, Cup warmer

## Multi-Beverage

- Milk Variations: Frothing degree adaptor, Integrated auto milk function, Milk quantity selector, Removable milk carafe

## Technical specifications

- Cord length: 80 cm
- Voltage: 120 V
- Boiler material: Stainless steel (Inox)
- Power: 1400 W
- Frequency: 60 Hz

## Weight and dimensions

- Coffee bean capacity: 250 g
- Product dimensions (L x D x H): 320 x 415 x 370 mm
- Product weight: 9.9 kg
- Waste container capacity: 14 servings
- Water tank capacity: 1.7 L

## Easy to use

- Cleaning and maintenance: Automatic coffee circuit rinse, Automatic milk circuit rinse, Descaling cycle
- Usage: Adjustable coffee dispenser, Bypass for grinded coffee, Cup holding surface, Frontal access to all function, Instant steam (2 boilers), Removable brewing group, Removable watertank

## Sustainability

- Automatic Stand-by Option