

Philips
Jamie Oliver Food
processor

1000 W
3.4 L bowl
8 accessories

HR7782/01



Speed up your cooking

With new serrated knife for quick frozen desserts

"I use my food processor every day. This one chops like a ninja and speeds up every aspect of my cooking, whether I'm slicing, shredding or mixing. It can even be used to knock up a quick ice cream. It's a great kitchen shortcut" Jamie O.

Confidently control power and speed settings

- PowerChop technology for superior chopping performance

Easy processing and effortless cleaning

- Dishwasher safe accessories

Easy processing and effortless cleaning

- XXL 18cm discs for faster execution of all ingredients

Get inspired to create more fresh meals

- Visit www.philips.com/jamieoliver for more tips
- Exclusive Jamie Oliver recipes for inspiration

Saves time while preparing fresh healthy food

- Metal double balloon beater for egg whites and cream
- Innovative serrated knife for quick frozen desserts
- Reversible shredding disc (fine or coarse)
- Adjustable slicing disc for thin to thick slices (1 - 7 mm)

PHILIPS

Jamie Oliver Food processor
1000 W 3.4 L bowl, 8 accessories

Highlights

Reversible shredding disc



Cooking delicious meals for friends and family doesn't have to be time consuming. This reversible shredding disc ensures that onions, carrots, zucchinis and potatoes are grated in seconds. Useful for curries, salads, stews and gratins - and maybe a great way to bring more vitamins and fibres into your diet!

Metal double balloon beater



The double metal balloon beater creates fluffy egg whites and perfectly whipped cream. For best results, use speed 1, which ensures the most fluffy results. Creating delicious desserts has never been easier!

Innovative serrated knife



Busy parents can now treat their children (or themselves) to healthy frozen desserts. This innovative serrated knife makes instant "ice creams" from frozen berries, yoghurt and

honey in a matter of seconds. Thanks to the serrated edges, crushing ice cubes is quick and simple too.

Adjustable slicing disc



"We all lead increasingly busy lives, so saving time in the kitchen while still putting tasty and nutritious food on the table is incredibly important. I want busy parents to feel as comfortable as possible using the new Food Processor, which will give back some extra special time to spend with family or friends by reducing meal preparation time." This slicing disc is easily adjusted to enable a variety of different thicknesses of apples, potatoes or other ingredients.

Exclusive Jamie Oliver recipes



Each product in the range of Jamie's Tools by Philips Jamie Oliver comes with exclusive recipes from Jamie to help prepare a range of easy, fresh dishes that all the family will love.

Jamie's Tools



"For me, it's about encouraging more people to enjoy cooking and to feel as comfortable

HR7782/01

and confident as possible using this kit. And, ultimately, I set out to design a range that I would be genuinely happy to have and use in my own kitchen. Every piece of kit from the Jamie's Tools range by Philips Jamie Oliver has a splash of lovely cornflower blue, the color I chose to match the clean retro shapes we've used. This stuff is meant to be shown off, not hidden away in cupboards."

PowerChop technology



PowerChop

PowerChop technology is a combination of blade shape, cutting angle and inner bowl that provides a superior chopping result in both soft and hard ingredients. It is also perfect for making purées and mixing your cake batters!

Dishwasher safe accessories



All Philips Food Processor accessories included in your box are dishwasher safe.

XXL Discs for faster execution

Thanks to the XXL discs (18cm), the Philips food processor will provide you a faster performance saving you time and effort while cooking.

Specifications

Country of origin

- China

Technical specifications

- Cord length: 1.2 m
- Voltage: 220-240 V
- Frequency: 50/60 Hz
- Safety: Lid & bowl detection, mechanical 1.5 sec brake

General specifications

- Non-slip feet
- Speeds: 2 + pulse
- RPM-Blender&Grinder Mill(max): Up to 20000 rpm
- RPM-Bowl(max): Up to 1700 rpm
- RPM-Bowl(min): Up to 575 rpm
- Main unit with bowl: 289x254x436 mm

Accessories

- Adjustable slicing disc: 1-7 mm
- Kneading tool: For (heavy) kneading, mixing dough, batter
- Balloon beater: For whipping, whisking, mixing and emulsifying

- Stainless steel chopping knife: Beating, chopping, creaming, crumbling, cutting, folding in, mashing, mincing
- Citrus press: For pressing of citrus fruits
- Stainless steel S-blade
- Number of inserts/discs: 2

Design specifications

- Color(s): Star white & horizon blue
- Housing: ABS
- Speed knob: ABS
- Bowl including lid and blender: SAN
- Disks, chopping blade: Stainless steel
- Function buttons: Pulse
- Kneading tool, citrus press: PP
- Pusher, inner pusher: ABS, SAN
- Knife holder, balloon beater: POM

Dimensions and weight

- Packaging dimensions (L×W×H): 34.5x53x27 cm
- Product dimensions (L×W×H): 324.3x273.6x412.1 mm

General specifications

- Integrated cord storage



Issue date 2022-07-08

Version: 1.1.1

EAN: 08 71010 35951 82

© 2022 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com