



Philips Shaver series 7000  
Wet and dry electric  
shaver

**SkinGlide Rings**  
GentlePrecisionPRO Blades  
SmartClick precision trimmer

## Smooth glide, sensitive shave

Philips' no 1 on sensitive skin\*

The Philips series 7000 protects against the key signs of skin irritation. SkinGlide rings with anti-friction coating enable the shaver to glide effortlessly across your face. Its blades cut close and protect skin, even with 3-day stubble.

### Easy to use

- Intuitive display with 1-level battery indicator
- 50 minutes of cordless shaving
- Shaver can be rinsed clean under the tap
- Comes with a 2-year guarantee

### A close and smooth shave

- Blades protect skin and cut close even with 3-day stubble

### Designed for maximum skin comfort

- SkinGlide rings with anti-friction coating for smooth glide
- Aquatec gives you a comfortable dry or refreshing wet shave
- 5 direction flex heads follow contours with less pressure

### Get the most out of your shaver

- Even-up your mustache and sideburns

S7370/12

**PHILIPS**

# Highlights

## SkinGlide rings



Experience a more comfortable shave with anti-friction SkinGlide rings coated with microspheres. Thousands of tiny glass-like rounded spheres reduce friction and surface resistance between the shaver and the skin. This gives the shaver a smooth, easy glide and helps protect against skin irritation.

## 5-direction Dynamic Flex Heads



Our shaver heads flex easily in 5 directions, gently following all the contours of the face and neck. Less pressure is needed to shave closely and skin stress is minimized.

## GentlePrecision PRO blades



Our updated cutting system has skin protection technology, designed to only cut hair not skin. V shaped blades guide the skin away from the blades for a close smooth shave - even on 3-day stubble.

## 1 level battery indicator



The intuitive display shows relevant information, enabling you to get the best performance out of your shaver: 1-level battery indicator - cleaning indicator - battery low indicator - replacement head indicator - travel lock indicator

## Aquatec Wet & Dry



Adapt your shave routine to your needs. With the Aquatec Wet & Dry, you can go for a comfortable dry shave or a refreshing wet shave. You can shave with gel or foam even under the shower.

## 50 minutes of cordless shaving



The energy-efficient, powerful lithium-ion battery system gives you two convenient options: Charge it for an hour for up to 50 minutes of shaving time, or a quick charge for one full shave. All Shaver series 7000 models are designed to operate only in cordless mode to ensure safety in wet environments.

## Built to last



We back this Philips shaver with a 2-year guarantee. Our Series 7000 shavers are designed for performance and durability.

## Fully washable shaver



Simply open the shaver head to rinse it thoroughly under the tap.

## SmartClick Precision Trimmer



Refine and define your mustache and sideburns with the SmartClick precision trimmer—and complete your look with ease.

# Specifications

## Shaving Performance

- Shaving system: GentlePrecisionPRO Blades
- Contour following: 5-direction DynamicFlex Heads
- SkinComfort: SkinGlide Rings, SkinProtection System, AquaTec Wet & Dry

## Accessories

- Pouch: Travel pouch
- SmartClick: Precision trimmer

## Ease of use

- Wet & Dry: Wet and dry use
- Cleaning: Fully washable
- Display: 1 level battery indicator, Battery low indicator, Cleaning indicator, Replace shaving heads indicator, Travel lock indicator
- Operation: Cordless use, Unplug before use

## Design

- Handle: Ergonomic grip & handling

- Frame color: White
- Front color: Tesla ocean blue

## Power

- Automatic voltage: 100-240 V
- Battery Type: Lithium-ion
- Run time: 50 min / 17 shaves
- Charging: 1 hour full charge, Quick charge 5 min for 1 shave
- Stand-by power: 0.15 W
- Max power consumption: 5.4 W

## Service

- Replacement head: Replace every 2 yrs with SH70
- 2-year guarantee

## Software

- Software update: Philips offers relevant software updates for a period of 2 years after the date of purchase



Issue date 2022-07-24

Version: 9.4.1

© 2022 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)

\* Philips' no.1 on sensitive skin - compared to other Philips shavers