

PHILIPS

Dry electric shaver

Shaver series 5000

MultiPrecision Blade System

5-direction Flex Heads

SmartClick precision trimmer



S5100/08



Close, Fast Shave

The Shaver Series 5000 adds speed to your morning routine with a fast, MultiPrecision Blade System and fully washable heads.

Easy to use

- Shaver can be rinsed clean under the tap
- 1-level battery and travel lock Indicators
- 40 minutes of cordless shaving
- 1-hour charging time
- 2-year guarantee, worldwide voltage and replaceable blades

A comfortable and close end result

- Heads flex in 5 directions for a fast close shave
- Blades raise then cut long and short hairs for a fast shave
- Lifts hairs to cut comfortably close

Get the most out of your shaver

- Click-on trimmer for perfect mustache and sideburn trimming

Highlights

MultiPrecision Blade System



Get a shave that's fast and close. Our MultiPrecision Blade System raises and cuts all hairs and remaining stubble – all in a few strokes.

5-direction Flex Heads



5-direction Flex Heads with 5 independent movements ensure close skin contact for a fast and close shave even on neck and jaw line.

One touch open



Simply pop the heads open, and rinse thoroughly under the tap.

LED display



The intuitive display shows relevant information, enabling you to get the best performance out of your shaver: - 1-level Battery Indicator - Cleaning Indicator - Battery Low Indicator - Replacement Head Indicator - Travel Lock Indicator

40 minutes of cordless shaving



You'll have 40+ minutes of running time – that's about 13 shaves – on a one-hour charge. Or choose to shave with the device plugged in.

1-hour charging time



Shave longer with every charge, thanks to our powerful energy-efficient, long-lasting lithium-ion battery. Do a quick charge for 5 minutes and you'll have enough power for one shave.

SmartClick precision trimmer

Click on our skin-friendly precision trimmer to finish your look. It's ideal for maintaining your mustache and trimming your sideburns.

Super Lift & Cut Action



Shave closer with the dual-blade Super Lift & Cut Action. The first blade raises each hair while the second blade comfortably cuts below skin level, for really smooth results.

Built to last



All of our shavers come with a 2-year worldwide guarantee and can adapt to any voltage. The long-lasting blades only need to be replaced after 2 years.

Specifications

Accessories

SmartClick: Precision trimmer

Maintenance: Protective cap

Power

Battery Type: Lithium-ion

Charging: 1 hour full charge, Quick charge 5 min for 1 shave, Rechargeable

Run time: 40 min / 13 shaves

Automatic voltage: 100-240 V

Stand-by power: 0.1 W

Max power consumption: 9 W

Design

Handle: Ergonomic grip & handling

Color: Charcoal Grey - Dark Royal Blue

Service

2-year guarantee

Replacement head: Replace every 2 yrs with SH50

Shaving Performance

Contour following: 5-direction Flex Heads

Shaving system: MultiPrecision Blade System, Super Lift & Cut Action

Ease of use

Display: 1 level battery indicator, Battery low indicator, Charging indicator, Cleaning indicator, Replace shaving heads indicator, Travel lock indicator

Cleaning: Fully washable

Operation: Corded & Cordless use

