



### Philips Avance Collection Hand blender

800W, SpeedTouch with Turbo

ProMix Titanium Technology  
2 times finer blending\*  
Up to 50% faster\*



HR1673/91

## Powerful and easy control handblender

Make a variety of foods your way with SpeedTouch

Powerful Philips handblender with 800 Watt motor power, Promix blending technology and SpeedTouch button for intuitive control: The more you squeeze, the more power. With this hand blender you make fresh food results the way you like it.

#### Best blending results in seconds

- Optimal food flow and blending performance
- Powerful 800W motor for great blending results

#### Reliable and durable

- Titanium coated blades: 6x harder than steel

#### Versatile and multi-functional

- XL Chopper to chop onions, meat, nuts, cheese, chocolate
- Whisk accessory for whipping cream, mayonnaise and more
- Chopper to chop herbs, nuts, cheese, chocolate and onions
- 1L ProMix Beaker for optimal blending, whisking and mixing

#### Intuitive and easy to use

- Anti-splash blade guard with special wave shape
- Ergonomically designed grip for secure and easy handling
- Single button release for easy assembly
- SpeedTouch technology to intuitively set the right speed

# PHILIPS

Hand blender  
800W, SpeedTouch with Turbo ProMix Titanium Technology, 2 times finer blending\*, Up to 50% faster\*

HR1673/91

## Highlights

### ProMix blending technology



Developed together with the prestigious Stuttgart University, Philips ProMix is a unique, advanced technology that uses a specific triangular shape to create optimal food flow and maximum performance for faster and more consistent blending.

### Powerful 800 Watt motor



Powerful and reliable 800W motor that can drive a large variety of accessories to allow processing of almost any ingredient and deliver great results during food preparation.

### SpeedTouch with Turbo boost



Intuitive variable speed setting and turbo boost in one button that gives you more power as

you squeeze. Start slowly to prevent splashing and smoothly speed up till you reach the required speed for each application and every type of ingredient. Prepare all your favorite recipes at the touch of a button.

### Titanium coated blade



Titanium layer coating (TiN) that makes the knife six times harder than a regular stainless steel knife and ensures great performance over time. Combined with optimized knife shape and unique ProMix triangular shape of the bar for the best blending results. It is food safe.

### XL Chopper accessory



With the XL chopper accessory (1000ml) for a Philips hand blender you can chop large quantities of meat, herbs, nuts, cheese, chocolate and onions in seconds.

### Compact chopper accessory



With the compact chopper accessory of the Philips hand blender you can chop herbs, nuts, cheese, chocolate and onions.

### Whisk accessory



Single whisk accessory for Philips hand blender for whipping cream, mayonnaise, pan cake batter and more. Makes your hand blender multifunctional and versatile.

### Anti-splash blade guard



The special wave shape in the bottom part of the handblender blending bar guarantees no splashes or mess while you blend.

Hand blender  
800W, SpeedTouch with Turbo ProMix Titanium Technology, 2 times finer blending\*, Up to 50% faster\*

HR1673/91

# Specifications

## Technical specifications

- Cord length: 1.2 m
- Voltage: 220-240 V
- Power: 800 W
- Capacity compact chopper: 300 ml
- Capacity beaker: 1 L
- Frequency: 50/60 Hz
- Capacity XL chopper: 1000 ml

## Accessories

- Included: Compact chopper, Whisk, XL chopper 2-blade, Beaker

## Design

- Color: Black

## Service

- 2-year worldwide guarantee

## Sustainability

- Packaging: > 90% recycled materials
- User manual: 100% recycled paper

## General specifications

- Product features: Detachable shaft, Dishwasher safe, Turbo function, Variable speed

## Finishing

- Material of main body: ABS plastic
- Material accessories: SAN plastic
- Material bar: Metal
- Material blade: Titanium



Issue date 2022-07-25

Version: 1.1.1

EAN: 08 71010 38235 99

© 2022 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)

\*\*Compared to Philips Hand blender with bell-shaped blade chamber  
in internal test on tomato and uncooked vegetables