

Philips Jewel  
Vacuum cleaner with bag

**2000W**  
HEPA 12 filter  
3L  
Anti-Allergy

**FC9064/02**



## Beautiful results in a blink of an eye

### TriActive nozzle with unique 3-in-1 action

The Jewel range is ideal for those who want beautiful results fast. It comes with the patented Tri-active nozzle that gives you three cleaning actions in one stroke.

#### **Clean air in your home**

- Super Clean Air HEPA 12 filter, 99.5% filtration

#### **Easy cleaning, even around furniture**

- TriActive nozzle with unique 3-in-1 action

#### **Beautiful floors in a blink of an eye**

- 2000 Watt motor generating max. 450 Watt suction power

# PHILIPS

Vacuum cleaner with bag  
2000W HEPA 12 filter, 3L, Anti-Allergy

# Specifications

## Design

- Color: Deep red

## Performance

- Input power (max): 2000 W
- Input power (IEC): 1800 W
- Noise level (Lc IEC): 76 dB
- Suction power (max): 450 W
- Vacuum (max): 32 kPa
- Airflow (max): 43 l/s

## Usability

- Action radius: 10 m
- Tube coupling: Button
- Cord length: 7 m
- Carrying handle: Front
- Power control: Electronic on appliance

- Tube type: Metal lacquered 2-piece telescopic tube
- Wheel type: Plastic
- Dust full indicator
- Clean Comfort cassette

## Nozzles and accessories

- Standard nozzle: TriActive nozzle
- Accessories included: Crevice tool, Small nozzle

## Weight and dimensions

- Weight of product: 5.7 kg

## Filtration

- Dust capacity: 3 L
- Dust bag type: s-bag
- Exhaust filter: Super Clean Air HEPA 12 filter

FC9064/02

# Highlights

## 2000 Watt motor



Highly efficient 2000 Watt motor generates max. 450 Watt suction power for perfect cleaning results.

## Super Clean Air HEPA 12 filter



This Super Clean Air HEPA 12 filter catches at least 99.5% of all harmful microscopic vermin that causes respiratory allergies.

## TriActive nozzle



The TriActive nozzle cleans your floor in 3 ways in one go: 1) A larger opening at the tip of the nozzle easily sucks up big bits. 2) It has maximum cleaning efficiency due to optimized airflow through the nozzle. 3) The two side brushes sweep up the dust and dirt closely alongside furniture and walls.



Issue date 2022-09-14

Version: 1.1.1

© 2022 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)