

Philips Daily Collection  
Metal Kettle-Spring Lid,  
Light indicator

## Metal

Spring lid  
Light indicator  
1.7 L

HD9350/90



## Designed to last

For long and reliable daily use

Durable kettle in safe, food-grade stainless steel for long and reliable daily use. Philips brings 60 years of trust and expertise to this elegant long-life kettle.

### Safe to use

- Strix controller

### Easy to experience

- Save up to 66% energy with the cup indicators

### Fast, safe boiling

- Food grade stainless steel metal (SUS304)
- Flat heating element for fast boiling
- Micro-mesh filter captures tiny limescale particles
- Multi safety system against boil-dry

### Simple to fill, use and clean

- Cord winder for easy adjustment and storage
- Cordless kettle with 360° pirouette base
- Easy refilling through lid or spout
- Easy-to-read water level indicator
- Spring lid with large opening for cleaning

# PHILIPS

# Highlights

## Cup indicator

The handy water level indicators, including one-cup indicator, make sure that you only boil the amount of water that you need, saving both energy (one cup of water 250ml vs 1L) and water and helping to contribute to a better environment.

## Food grade metal parts

Food grade stainless metal parts (SUS304) to guarantee a safe and clean cup of water.

## Micro-mesh filter



A removable micro-mesh filter on the spout captures tiny limescale particles as small as 200 microns to ensure a clear cup.

## Flat heating element



A concealed stainless steel heating element ensures fast boiling and easy cleaning.

## Multi safety system



Multi safety system against boil-dry, with auto-switch off when the water is ready.

## Pilot light



Elegant indicator light incorporated in the power switch illuminates when the kettle is turned on.

## Water level indicator



The water level is easy to read with an indicator located underneath the handle.

## Spring lid with large opening\*



A push-button lid opens smoothly at the touch of a button, avoiding steam contact. The large opening simplifies cleaning.

## Easy refilling



The kettle can be filled through the spout or by opening the spring lid.

## Cordless + 360° pirouette base



The cordless kettle sits on a 360° pirouette base for easy lifting and replacing.

# Specifications

## Weight and dimensions

- Dimensions of packaging (LxWxH): 198 x 228 x 244 mm
- Micromesh filter: 200 µm

## General specifications

- Ergonomic grip
- Easy spout filling
- Product features: 360 degrees base, Automatic shut-off, Boil-dry protection, Cord storage, Flat heating element, Non-slip feet, On/off switch, Pilot light, Spring lid, Wide opening lid
- Lid as well as spout filling

## Design

- Color: Stainless steel

## Technical specifications

- Power: 1850-2200 W
- Cord length: 0.75 m
- Capacity: 1.7 L
- Voltage: 220-240 V
- Frequency: 50/60 Hz

## Service

- 2-year worldwide guarantee

## Sustainability

- Packaging: > 90% recycled materials
- User manual: 100% recycled paper

## Finishing

- Material of main body: Stainless steel
- Material power switch: Polypropylene (PP)



Issue date 2023-03-12

Version: 7.7.1

© 2023 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)

\* 25% larger than regular Philips metal kettle HD9320