

# PHILIPS

## Dispenser

Bottom loading

one nozzle

UV

Micro P-Clean filtration

ADD4968GD



## Bottle water redefined

### With Micro P-Clean filtration and UV

With micro P-Clean filtration system, this bottled water dispenser effectively removes microplastics to ensure the cleanness of water. It also comes with UV light disinfection technology, killing up to 99.9% bacteria in the cold water tank.

#### Cleaner water

- Micro P-Clean filtration effectively removes microplastics\*
- Long-life filter with a capacity of 4000L\*\*\*
- UV-LED kills 99.9% bacteria in the cold water tank\*\*

#### Thoughtful design for your convenience

- ClearSmart indicator tells when to replace the filter
- QuickTwist filter change for easy filter replacement
- Compressor cools water efficiently
- Wide dispensing area fits various sizes of containers
- Z-shape 304 stainless steel water pipe

#### Safeness assured

- Child lock to prevent hot water burns

# Highlights

## Micro P-Clean filtration

Cleaner water assured with effective microplastics removed\*, thanks to the Micro P-Clean filtration system which comes with a fine filtration precision of 1 micro.

## Long-life filtration

The MicroClean filter has a filtration capacity of 4000L, which lasts for about 1 year\*\*\*.

## UV disinfection

Since there's no chlorine, bacteria tend to grow in the water that sits inside the bottle or the cold water tank. Therefore we have the advanced UV-LED light technology installed in the cold water tank which kills up to 99.9% bacteria\*\*. The UV-LED light activates for 1 hour once the dispenser is connected with power, and works for 1 hour for every 2 hours to make sure the water stay clean.

## ClearSmart filter indicator

ClearSmart indicator reminds you of on-time filter replacement to ensure the water quality. When the filter is approaching the end of life, the indicator starts to flash, and turns red when the filter lifetime ends.

## QuickTwist filter change

QuickTwist filter change for easy filter replacement; no professional service needed.

## Compressor cooling

Compressor cooling produces cool water more efficiently and faster, compared to conventional thermoelectric cooling.

## Wide water dispensing area

Wide dispensing area easily fits various sizes of cup, glass, bowl and even pot.

## Z-shape water pipe

The 304 stainless steel water pipe is anti-rust, and the Z-shape helps to reach the bottom of the bottle so that there's no remaining water.

## Child lock for hot water

Child lock for hot water keeps children safe from accidental hot water burns.

# Specifications

## General specifications

**Cold water temperature:** 10 °C

**Hot water temperature:** 90 °C

**Voltage and frequency:** 220V-240V~, 50Hz/60Hz

## Power

**Cooling:** 85W

**Heating:** 500W

## Filter specifications

**Filter precision:** 1 micro

**Filtration capacity:** 4000L

**Main filter media:** Carbon block

**Replacement filter cartridge:** ADD502

## Country of origin

**Water dispenser:** China

