

PHILIPS



On tap water
purifier

Micro Pure



WP3811

Pure water made easy with Micro Pure filter

Compact and easy to install water purifier that gives you pure water by removing bacteria, harmful organic compounds and chlorine while keeping all the good minerals in your water with a Micro Pure filter.

Pure water

- Removes all bacteria, harmful organic compounds and chlorine

Made easy

- Hi-flow with maximum rate of 2 liters per minute
- Pure Protect alert shows you when to replace the filter

Simplicity

- Quick Fit tap adapters for easy installation on your tap
- Advanced Quick Twist mechanism for easy filter replacement

Sustainability

- Maximum performance without the need of electricity

Highlights

Micro Pure filter

The Micro Pure filter is a multi-filtration system that removes all bacteria, impurities and odors for clean, safe and tasty drinking water. It consists of a hi-tech hollow-fibre membrane, which contains more than 520 billion micro-pores for the efficient removal of 99.99% of all bacteria, and granular activated carbon which removes unpleasant chlorine, bad taste and odors. The filter also preserves all good minerals in the drinking water that are vital for human health.

Pure Protect alert

The advanced and simple color-coded Pure Protect alert guides users to change the filter on time with maximum simplicity: when the membrane turns dark grey or rusty brown, it is time to replace the filter.

Hi-flow

This compact water purifier has a maximum flow rate of 2 liters per minute, which makes little change to the normal flow rate of unfiltered

water. By simply rotating the water selection lever, you also have a choice of either a stream or a spray of unfiltered water or spray of filtered water.

Quick Fit tap adapters

This advanced water purifier comes with a number of tailor-made Quick Fit tap adapters, to help you having an easy and simple installation of your purifier in your tap. Real sense and simplicity.

Quick Twist filter change

The advanced Quick Twist filter change mechanism makes changing the filter quick, easy and secure, bringing sense and simplicity to your water purifier.

No energy consumption

Designed to operate without electricity while offering maximum performance. Supports sustainability.

Specifications

Purification system

Turbidity removal: 3000 liters or approx. 1 year
Bacteria removal: 99.99 %
VOC Removal
Chlorine removal: >75 %

Design specifications

Color(s): white
Materials: plastic
Product weight: 230 g
Product dimensions (L x W x H): 60 x 137 x 105 mm

Filter specifications

Major filter components: hollow-fiber membrane, granular activated carbon GAC
Filter lifetime: 2400 L or approx. 8 months

Input water conditions

Min. input water pressure: 0.7 bar
Max. input water temperature: 50 °C
Max. input water pressure: 3.5 bar

General specifications

Replacement filter cartridge: WP3911
Accessories: 8 QuickFit tap-mounting adapters, PureProtect Alert
Water selection: filtered spray, unfiltered spray, unfiltered stream
Water flow rate: 2 l/min
Water flow rate: 5 °C

Sustainability

User manual: 100% recycled paper
Packaging: > 90% recycled materials

Country of origin

Water purifier: Japan
Replacement filter: Japan

