



Philips  
Dispenser

**Bottom loading**  
one nozzle  
Micro P-Clean filtration

**ADD4965SV**

## Bottle water redefined

With micro P-Clean filtration\*

With micro P-Clean filtration system, this bottled water dispenser effectively removes microplastics\* to ensure the cleanness of water.

### Cleaner water

- Micro P-Clean filtration effectively removes microplastics\*
- Long-life filter with a capacity of 4000L\*\*\*

### Thoughtful design for your convenience

- Compressor cools water efficiently
- ClearSmart indicator tells when to replace the filter
- Wide dispensing area fits various sizes of containers
- QuickTwist filter change for easy filter replacement
- Z-shape 304 stainless steel water pipe

### Safeness assured

- Child lock to prevent hot water burns

**PHILIPS**

Dispenser  
Bottom loading one nozzle, Micro P-Clean filtration

# Specifications

## Filter specifications

- Filtration capacity: 4000L
- Main filter media: Carbon block
- Filter precision: 1 micro
- Replacement filter cartridge: ADD502

## General specifications

- Voltage and frequency: 220V-240V~, 50Hz/60Hz

- Cold water temperature: 10 °C
- Hot water temperature: 90 °C

## Power

- Cooling: 85W
- Heating: 500W

## Country of origin

- Water dispenser: China

ADD4965SV/56

# Highlights

## Micro P-Clean filtration

Cleaner water assured with effective microplastics removed\*, thanks to the Micro P-Clean filtration system which comes with a fine filtration precision of 1 micro.

## Long-life filtration

The MicroClean filter has a filtration capacity of 4000L, which lasts for about 1 year\*\*\*.

## ClearSmart filter indicator

ClearSmart indicator reminds you of on-time filter replacement to ensure the water quality. When the filter is approaching the end of life, the indicator starts to flash, and turns red when the filter lifetime ends.

## QuickTwist filter change

QuickTwist filter change for easy filter replacement; no professional service needed.

## Compressor cooling

Compressor cooling produces cool water more efficiently and faster, compared to conventional thermoelectric cooling.

## Wide water dispensing area

Wide dispensing area easily fits various sizes of cup, glass, bowl and even pot.

## Z-shape water pipe

The 304 stainless steel water pipe is anti-rust, and the Z-shape helps to reach the bottom of the bottle so that there's no remaining water.

## Child lock for hot water

Child lock for hot water keeps children safe from accidental hot water burns.



Issue date 2023-12-27

Version: 3.0.1

EAN: 48 97099 30227 8

© 2023 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)

\* Tested according to NSF testing protocols by 3rd party  
ISO9001:2015 accredited laboratory with particles down to 2  
microns.

\*\*Tested by internal laboratory. Assuming water consumption of  
10L per day.