

Philips
UV water purifier

UV Class A

WP3890/01



Pure water or no water

with Pure Protect Lock

Pure water or no water with Power UV+ removes bacteria, viruses and cysts, and improves the taste of water. Pure Protect Lock locks purifier from dispensing impure water when filter reaches end of life or an error is detected in the purifier.

Pure water

- Advanced UV technology and activated carbon to purify water

Guaranteed

- Conforms to safety standards of Bureau of Indian Standards
- WQA has certified and awarded the Gold Seal to this product
- Microbiological performance tested as per NSF55 Class A
- PureProtect alert warns you when filter needs replacement

Simplicity

- Tilt and Twist mechanism for easy filter replacement

Made easy

- PowerSave ensures low electricity consumption
- Hi-flow with maximum rate of 1.2 litres per minute
- Musical reminder lets you know when dispenser is on

PHILIPS
sense and simplicity

Specifications

General specifications

- Frequency: 50 Hz
- Voltage: 220-240 V
- Water flow rate: max 1.2 l/min
- Power rating: 25 W

Design specifications

- Product weight: 3.6 kg
- Product dimensions (L x W x H): 287 x 156 x 422 mm

Purification system

- PLS UV lamp: 9 W

Water input conditions

- Max. input water temperature: 45 °C
- Max. input water pressure: 2.0 Bar
- Min. input water pressure: 0.5 Bar
- Min. input water temperature: 5 °C

Highlights

Power UV+

Advanced state-of-the-art UV (PLS) technology destroys known waterborne viruses, bacteria, parasites and amoebae while the activated carbon and sediment filter removes turbidity, chlorine, volatile organic chemicals (VOCs), cysts, larger micro-organisms and improves taste.

Tilt and Twist

Replacing the filter is something you can easily do yourself thanks to the simple Tilt and Twist mechanism.

PowerSave

This appliance has low electricity consumption and is rated at 25 watts. To make it even more energy efficient, the UV lamp switches off when the appliance has not been used for 10 minutes.

Hi-flow

The maximum flow rate of 1.2 litres per minute ensures that you have safe drinking water available at any time.

Certified by BIS

Product is certified according to microbiological performance standard BIS 14724 and Drinking water standard BIS 10500 by the Bureau of Indian Standards

Musical reminder

While the purifier is dispensing water, an optional musical reminder will notify you that the dispenser is on.

Gold Seal by Water Quality Association (WQA), USA



WQA (Water Quality Association, USA) only awards the Gold Seal to those systems, components or additives that have met or exceeded industry standards for contaminant reduction, structural integrity and material safety. This product is certified by WQA to conform to NSF/ANSI 42 for the removal of chlorine and particulates (removes all classes of particulates from Class I till Class VI - particle size 0.5µm till 80 µm), NSF/ANSI 53 for the removal of turbidity, volatile organic chemicals (VOCs) and cysts and NSF/ANSI 55 Class A for microbiological dis-infection.

Tested by KIWA Water Research, The Netherlands

Tested by Kiwa Water Research: Microbiological performance tested by Kiwa Water Research (The Netherlands) according to the NSF standard 55, Class A protocol (2004).

PureProtect alert

After 2700 litres of water consumption, PureProtect alert sends out a signal. There will still be enough capacity for another 300 litres after the signal.



Issue date 2010-12-24

Version: 10.1.1

12 NC: 0000 000 00000

© 2010 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com