



Philips  
Replacement filter for on  
tap purifier

Micro Pure

WP3911

## Pure water made easy

### Micro Pure filter

Advanced filtration system that gives you pure water by removing bacteria, harmful organic compounds and chlorine, while keeping all the good minerals in your water.

#### **Pure water**

- Removes all bacteria, harmful organic compounds and chlorine

#### **Simplicity**

- Advanced Quick Twist mechanism for easy filter replacement

# PHILIPS

# Specifications

## Purification system

- Turbidity removal: 3000 liters or approx. 1 year
- VOC Removal
- Bacteria removal: 99.99 %
- Chlorine removal: >80 %

## Design specifications

- Color(s): white
- Materials: plastic
- Product weight: 150 g
- Product dimensions (L x W x H): 60 x 64 x 105 mm

## Filter specifications

- Filter lifetime: 2400 L or approx. 8 months
- Major filter components: hollow-fiber membrane,

granular activated carbon GAC

## Input water conditions

- Min. input water pressure: 0.7 bar
- Max. input water pressure: 3.5 bar
- Max. input water temperature: 50 °C

## General specifications

- Water flow rate: 2 l/min
- Water flow rate: 5 °C

## Sustainability

- Packaging: > 90% recycled materials

## Country of origin

- Replacement filter: Japan

# Highlights

## Micro Pure filter

The Micro Pure filter is a multi-filtration system that removes all bacteria, impurities and odors for clean, safe and tasty drinking water. It consists of a hi-tech hollow-fibre membrane, which contains more than 520 billion micro-pores for the efficient removal of 99.99% of all bacteria, and granular activated carbon which removes unpleasant chlorine, bad taste and odors. The filter also preserves all good minerals in the drinking water that are vital for human health.

## Quick Twist filter change

The advanced Quick Twist filter change mechanism makes changing the filter quick, easy and secure, bringing sense and simplicity to your water purifier.



Issue date 2024-10-03

Version: 5.5.1

© 2024 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)