



Philips AquaShield  
Water filter pitcher

**Microfiltration**  
GAC + Ion exchange resin  
1.5L tank for filtered water

**AWP2921**

## Clean water made easy

Microfiltration system removes lead and chlorine

With multi-stage microfiltration system, this water filter pitcher reduces VOCs, herbicide and up to 99% chlorine and lead for healthy and tasty drinking water. It also reduces water hardness.

### **Cleaner water**

- Effectively reduces lead, pesticides, VOCs and chlorine

### **Made easy**

- Digital timer reminds you when to replace the filter
- Dust-proof spout keeps water fresh and clean
- Ergonomic handle that is comfortable to hold and carry
- Simply discard the one-piece filter after use

**PHILIPS**

Water filter pitcher  
Microfiltration GAC + Ion exchange resin, 1.5L tank for filtered water

AWP2921/11

# Specifications

## General specifications

- Water flow rate: 0.25L/min
- Replacement filter cartridge: AWP200/AWP201

## Country of origin

- Pitcher: China
- Filter: China

## Filter specifications

- Main filter media: Granular activated carbon/GAC, Ion exchange resin
- Filtration capacity: 200L

## Filtration performance

- Soluble lead reduction: Yes, up to 99%\*
- Chlorine reduction: Yes, up to 99%\*
- Water hardness reduction
- Bacteria removal: N/A

## Input water conditions

- Input water pressure: (atmospheric) 0-1 bar
- Input water temperature: 5-38 °C
- Input water quality: Municipal tap water

# Highlights

## One-piece disposable filter

Simply discard the one-piece filter when it reaches the end of lifetime. The one-piece design prevents secondary pollution.

## Dust-proof spout

By preventing dust from getting in through the water outlet, the dust-proof spout keeps the water fresh and clean.

## Ergonomic handle

Ergonomically designed, the handle is very comfortable to hold, which makes it easy to carry the pitcher.

## Digital timer

Digital timer reminds you when to replace the filter for the best result.

## 4-staged microfiltration

The 4-stage filtration system consists of non-woven fabric, granular activated carbon, resin and another layer of non-woven fabric, which effectively reduces pesticides, chemicals, microplastics, and up to 99% lead\* and chlorine for crisp and pure tasting water. It also reduces water hardness.



Issue date 2020-08-23

Version: 3.0.1

12 NC: 8670 001 61625  
EAN: 48 97099 30004 5

© 2020 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)

\* \*\*Based on test result by the international certification testing agency BV under laboratory conditions. Soluble lead reduction is still at 88% when the filter lifetime ends.