

PHILIPS

Replacement filter
for on tap purifier

Pure Taste



WP3961



Better-tasting water made easy

Pure Taste filter

Improves the taste of your drinking and cooking water by removing chlorine and other impurities with a silver-coated active carbon system.

Better-tasting water

- Pure Taste filter for cleaner and better tasting water

Made easy

- Hi-flow with maximum rate of 2 liters per minute

Simplicity

- Advanced Quick Twist mechanism for easy filter replacement

Highlights

Pure Taste filter

The Pure Taste filter removes unpleasant chlorine, bad tastes and smells, as well as large sediment from your tap water, ensuring purer and better tasting water for drinking, cooking and cleaning fruits and vegetables. In addition, the silver-coated active carbon prevents bacteria growth inside the filter, giving you extra safety for your water.

Hi-flow

This compact water purifier has a maximum flow rate of 2 liters per minute, which makes little change to the normal flow rate of

unfiltered water. By simply rotating the water selection lever, you also have a choice of either a stream or a spray of unfiltered water or spray of filtered water.

Quick Twist filter change

The advanced Quick Twist filter change mechanism makes changing the filter quick, easy and secure, bringing sense and simplicity to your water purifier.

Specifications

General specifications

Water flow rate: 2 l/min

Water flow rate: 5 °C

Design specifications

Color(s): white

Product weight: 50 g

Product dimensions (L x W x H): 44 x 44 x 90 mm

Materials: plastic

Purification system

Chlorine removal: >80 %

Turbidity removal: 3000 liters or approx. 1 year

Filter specifications

Filter lifetime: 2000 L or approx. 6 months

Major filter components: silver-coated GAC

Input water conditions

Min. input water pressure: 0.7 bar

Max. input water pressure: 3.5 bar

Max. input water temperature: 50 °C

Country of origin

Replacement filter: Japan

Sustainability

Packaging: > 90% recycled materials

