

Philips
On-tap filtration

Microfiltration

GAC
0.4L/min

AWP3702



Clean water right from the tap

Remove residual chlorine and odor

Compact on-tap purifier using high quality granular activated carbon to effectively removes residual chlorine and odors, ensuring clean and tasty water for you and your family.

Cleaner water

- Removes residual chlorine and odors effectively

Made easy

- Buckle type release and lock filter changing mechanism
- Water control system with optional water outlet modes
- Quick Fit tap adapters for easy installation on your tap
- Simply discard the one-piece filter after use

PHILIPS

On-tap filtration
Microfiltration GAC, 0.4L/min

Specifications

General specifications

- Rated water flow rate: 0.4L/min

Country of origin

- Filter: China
- System: China

Filter specifications

- Main filter media: Granular activated carbon/GAC
- Filtration capacity: 1000L

Filtration performance

- Chlorine reduction: Yes, up to 99%*
- Pesticide removal
- VOC reduction

Input water conditions

- Input water pressure: 1.5-3.5 bar
- Input water temperature: 5-38 °C
- Input water quality: Municipal tap water

AWP3702/90

Highlights

Refreshing and tasty water

Granular activated carbon filter can remove residual chlorine by more than 99%*, and adsorbs odors effectively.

Filters are easily changed

Eject the used filter by pushing the switch and simply insert the new one.

Ingenuity design

A simple rotation of the water selection lever switches the water flow from regular, unfiltered tap water (stream or spray) to effectively treated filtered water.

Quick Fit tap adapters

This on-tap purifier comes with a few tailor-made Quick Fit tap adapters, which fit most taps and help you to easily install the filter.

One-piece disposable filter

Simply discard the one-piece filter when it reaches the end of lifetime. The one-piece design prevents secondary pollution.



Issue date 2020-08-23

Version: 3.0.1

12 NC: 8670 001 62929
EAN: 48 97099 30079 3

© 2020 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com