



Philips  
Dispenser

### Bottom loading

one nozzle  
UV  
Micro P-Clean filtration

**ADD4972BKS**

## Bottle water redefined

With Micro P-Clean filtration and UV

With micro P-Clean filtration system, this bottled water dispenser effectively removes microplastics to ensure the cleanness of water. It also comes with UV light disinfection technology, killing up to 99.9% bacteria in the cold water tank.

#### Cleaner water

- Micro P-Clean filtration effectively removes microplastics\*
- Long-life filter with a capacity of 4000L\*\*\*
- UV-LED kills 99.9% bacteria in the cold water tank\*\*

#### Thoughtful design for your convenience

- ClearSmart indicator tells when to replace the filter
- QuickTwist filter change for easy filter replacement
- Compressor cools water efficiently
- Wide dispensing area fits various sizes of containers
- Z-shape 304 stainless steel water pipe

#### Safeness assured

- Child lock to prevent hot water burns

# PHILIPS

Dispenser  
Bottom loading one nozzle, UV, Micro P-Clean filtration

# Specifications

## General specifications

- Cold water temperature: 10 °C
- Hot water temperature: 90 °C
- Voltage and frequency: 220V-240V~, 50Hz/60Hz

## Power

- Cooling: 85W
- Heating: 500W

## Filter specifications

- Filter precision: 1 micro
- Filtration capacity: 4000L
- Main filter media: Carbon block
- Replacement filter cartridge: ADD502

## Country of origin

- Water dispenser: China

ADD4972BKS/56

# Highlights

## Micro P-Clean filtration

Cleaner water assured with effective microplastics removed\*, thanks to the Micro P-Clean filtration system which comes with a fine filtration precision of 1 micro.

## Long-life filtration

The MicroClean filter has a filtration capacity of 4000L, which lasts for about 1 year\*\*\*.

## UV disinfection

Since there's no chlorine, bacteria tend to grow in the water that sits inside the bottle or the cold water tank. Therefore we have the advanced UV-LED light technology installed in the cold water tank which kills up to 99.9% bacteria\*\*. The UV-LED light activates for 1 hour once the dispenser is connected with power, and works for 1 hour for every 2 hours to make sure the water stay clean.

## ClearSmart filter indicator

ClearSmart indicator reminds you of on-time filter replacement to ensure the water quality. When the filter is approaching the end of life, the indicator starts to flash, and turns red when the filter lifetime ends.

## QuickTwist filter change

QuickTwist filter change for easy filter replacement; no professional service needed.

## Compressor cooling

Compressor cooling produces cool water more efficiently and faster, compared to conventional thermoelectric cooling.

## Wide water dispensing area

Wide dispensing area easily fits various sizes of cup, glass, bowl and even pot.

## Z-shape water pipe

The 304 stainless steel water pipe is anti-rust, and the Z-shape helps to reach the bottom of the bottle so that there's no remaining water.

## Child lock for hot water

Child lock for hot water keeps children safe from accidental hot water burns.



Issue date 2022-06-29

Version: 1.0.1

12 NC: 8670 001 84836  
EAN: 48 95244 60394 2

© 2022 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)

\* Tested according to NSF testing protocols by 3rd party ISO9001:2015 accredited laboratory with particles down to 2 microns.

\*\* Tested by SGS under laboratory conditions.

\*\*\* Tested by internal laboratory. Assuming water consumption of 10L per day.