



Philips
Dispenser

Bottom loading

one nozzle
UV
Micro P-Clean filtration

ADD4972RGS

Bottle water redefined

With Micro P-Clean filtration and UV

With micro P-Clean filtration system, this bottled water dispenser effectively removes microplastics to ensure the cleanness of water. It also comes with UV light disinfection technology, killing up to 99.9% bacteria in the cold water tank.

Cleaner water

- Micro P-Clean filtration effectively removes microplastics*
- Long-life filter with a capacity of 4000L***
- UV-LED kills 99.9% bacteria in the cold water tank**

Thoughtful design for your convenience

- ClearSmart indicator tells when to replace the filter
- QuickTwist filter change for easy filter replacement
- Compressor cools water efficiently
- Wide dispensing area fits various sizes of containers
- Z-shape 304 stainless steel water pipe

Safeness assured

- Child lock to prevent hot water burns

PHILIPS

Dispenser
Bottom loading one nozzle, UV, Micro P-Clean filtration

Specifications

General specifications

- Cold water temperature: 10 °C
- Hot water temperature: 90 °C
- Voltage and frequency: 220V-240V~, 50Hz/60Hz

Power

- Cooling: 85W
- Heating: 500W

Filter specifications

- Filter precision: 1 micro
- Filtration capacity: 4000L
- Main filter media: Carbon block
- Replacement filter cartridge: ADD502

Country of origin

- Water dispenser: China

ADD4972RGS/56

Highlights

Micro P-Clean filtration

Cleaner water assured with effective microplastics removed*, thanks to the Micro P-Clean filtration system which comes with a fine filtration precision of 1 micro.

Long-life filtration

The MicroClean filter has a filtration capacity of 4000L, which lasts for about 1 year***.

UV disinfection

Since there's no chlorine, bacteria tend to grow in the water that sits inside the bottle or the cold water tank. Therefore we have the advanced UV-LED light technology installed in the cold water tank which kills up to 99.9% bacteria**. The UV-LED light activates for 1 hour once the dispenser is connected with power, and works for 1 hour for every 2 hours to make sure the water stay clean.

ClearSmart filter indicator

ClearSmart indicator reminds you of on-time filter replacement to ensure the water quality. When the filter is approaching the end of life, the indicator starts to flash, and turns red when the filter lifetime ends.

QuickTwist filter change

QuickTwist filter change for easy filter replacement; no professional service needed.

Compressor cooling

Compressor cooling produces cool water more efficiently and faster, compared to conventional thermoelectric cooling.

Wide water dispensing area

Wide dispensing area easily fits various sizes of cup, glass, bowl and even pot.

Z-shape water pipe

The 304 stainless steel water pipe is anti-rust, and the Z-shape helps to reach the bottom of the bottle so that there's no remaining water.

Child lock for hot water

Child lock for hot water keeps children safe from accidental hot water burns.



Issue date 2022-06-29

Version: 1.0.1

12 NC: 8670 001 84832
EAN: 48 95244 60393 5

© 2022 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com

* Tested according to NSF testing protocols by 3rd party ISO9001:2015 accredited laboratory with particles down to 2 microns.

** Tested by SGS under laboratory conditions.

*** Tested by internal laboratory. Assuming water consumption of 10L per day.