



Philips
Filter cartridge

X-Guard Ultra

AWP314

Crisp and pure tasting water

straight from the tap

Enjoy crisp and pure tasting water whenever you turn on the tap, with Philips X-Guard ultrafiltration system reducing chlorine, bacteria and more.

Crisp and pure tasting water

- Effectively reduces chlorine, pesticides, bacteria and more

Made easy

- Quick twist design for easy filter replacement

Good for you, and good for the environment

- Delicious water at a fraction of the cost of bottled water

PHILIPS

Filter cartridge
X-Guard Ultra

AWP314/59

Specifications

Filter specifications

- Filtration capacity: 800L

Input water conditions

- Input water pressure: 0.15 - 0.35Mpa bar
- Input water quality: Municipal tap water
- Input water temperature: 5-38 °C

Highlights

Easy filter replacement

Effortlessly replace the expired filter with a new one with a simple twist.

X-Guard Ultra filter

By adopting the innovative activated carbon fibre and hollow fibre membrane, this X-Guard Ultra filter effectively reduces chlorine, pesticides, microplastics and particles down to 0.1 micron. It also filters up to 99.99% of bacteria.

Economical and eco-friendly

Great tasting water at a fraction of the cost and waste of bottled water.



Issue date 2020-08-09

Version: 2.0.1

12 NC: 8670 001 71518
EAN: 48 97099 30318 3

© 2020 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com