

Dispenser

- Bottom loading
- one nozzle
- UV
- Micro P-Clean filtration

[ADD4972BKS/56](#)

# Bottle water redefined

With Micro P-Clean filtration and UV

With micro P-Clean filtration system, this bottled water dispenser effectively removes microplastics to ensure the cleanness of water. It also comes with UV light disinfection technology, killing up to 99.9% bacteria in the cold water tank.

## Benefits

### Cleaner water

- Micro P-Clean filtration effectively removes microplastics\*
- Long-life filter with a capacity of 4000L\*\*\*
- UV-LED kills 99.9% bacteria in the cold water tank\*\*

### Thoughtful design for your convenience

- ClearSmart indicator tells when to replace the filter
- QuickTwist filter change for easy filter replacement

- Compressor cools water efficiently
- Wide dispensing area fits various sizes of containers
- Z-shape 304 stainless steel water pipe

### Safeness assured

- Child lock to prevent hot water burns

## Features

### Micro P-Clean filtration

Cleaner water assured with effective microplastics removed\*, thanks to the Micro P-Clean filtration system which comes with a fine filtration precision of 1 micro.

### Long-life filtration

The MicroClean filter has a filtration capacity of 4000L, which lasts for about 1 year\*\*\*.



### UV disinfection

Since there's no chlorine, bacteria tend to grow in the water that sits inside the bottle or the cold water tank. Therefore we have the advanced UV-LED light technology installed in the cold water tank which kills up to 99.9% bacteria\*\*. The UV-LED light activates for 1 hour once the dispenser is connected with power, and works for 1 hour for every 2 hours to make sure the water stay clean.

### ClearSmart filter indicator

ClearSmart indicator reminds you of on-time filter replacement to ensure the water quality. When the filter is approaching the end of life, the indicator starts to flash, and turns red when the filter lifetime ends.

### QuickTwist filter change

QuickTwist filter change for easy filter replacement; no professional service needed.

## Specifications

[field not found 'disclaimer\_text']

### General specifications

Cold water temperature	10 °C
Hot water temperature	90 °C
Voltage and frequency	220V-240V~, 50Hz/60Hz

### Power

Cooling	85W
Heating	500W

### Compressor cooling

Compressor cooling produces cool water more efficiently and faster, compared to conventional thermoelectric cooling.

### Wide water dispensing area

Wide dispensing area easily fits various sizes of cup, glass, bowl and even pot.

### Z-shape water pipe

The 304 stainless steel water pipe is anti-rust, and the Z-shape helps to reach the bottom of the bottle so that there's no remaining water.

### Child lock for hot water

Child lock for hot water keeps children safe from accidental hot water burns.

### Filter specifications

Filter precision	1 micro
Filtration capacity	4000L
Main filter media	Carbon block
Replacement filter cartridge	ADD502

### Country of origin

Water dispenser	China
-----------------	-------

\* Tested according to NSF testing protocols by 3rd party ISO9001:2015 accredited laboratory with particles down to 2 microns.

\*\*Tested by SGS under laboratory conditions.

\*\*\*Tested by internal laboratory. Assuming water consumption of 10L per day.



data subject to change  
2022, March 19

Version: 1.0.1  
EAN: 4895244603942

© 2022 Koninklijke Philips N.V.  
All rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

[www.philips.com](http://www.philips.com)