



Philips  
Water filter pitcher

### Ultrafiltration

GAC + Hollow fiber membrane  
1.5L tank for filtered water

AWP2950

## Clean water made easy

Ultrafiltration system removes 99.9% bacteria

With multi-stage ultrafiltration system, this ergonomically designed water filter pitcher reduces chlorine, VOCs, herbicide, and up to 99.9% bacteria\* for healthy and tasty drinking water, while retaining beneficial minerals.

#### Cleaner water

- Effectively reduces 99.9% bacteria

#### Made easy

- Dust-proof spout keeps water fresh and clean
- Ergonomic handle that is comfortable to hold and carry
- Simply discard the one-piece filter after use

# PHILIPS

Water filter pitcher  
Ultrafiltration GAC + Hollow fiber membrane, 1.5L tank for filtered water

AWP2950/03

# Specifications

## General specifications

- Replacement filter cartridge: AWP260/AWP261
- Water flow rate: 0.15L/min

## Country of origin

- Pitcher: China
- Filter: China

## Filter specifications

- Main filter media: Granular activated carbon/GAC, Hollow fiber membrane
- Filtration capacity: 200L

## Filtration performance

- Bacteria removal: Yes, up to 99.9%\*
- Chlorine reduction
- Soluble lead reduction: N/A
- Water hardness reduction: N/A

## Input water conditions

- Input water pressure: (atmospheric) 0-1 bar
- Input water temperature: 5-38 °C
- Input water quality: Municipal tap water

# Highlights

## Ergonomic handle

Ergonomically designed, the handle is very comfortable to hold, which makes it easy to carry the pitcher.

## One-piece disposable filter

Simply discard the one-piece filter when it reaches the end of lifetime. The one-piece design prevents secondary pollution.

## 3-stage ultrafiltration

The 3-stage ultrafiltration system consists of non-woven fabric, granular activated carbon and hollow fiber membrane, which effectively reduces chlorine, pesticides, chemicals, and up to 99.9% bacteria\*. It also reduces particles down to 0.01 micron including microplastics for crisp and pure tasting water, while retaining beneficial minerals.

## Dust-proof spout

By preventing dust from getting in through the water outlet, the dust-proof spout keeps the water fresh and clean.



Issue date 2020-08-23

Version: 3.0.2

12 NC: 8670 001 61452  
EAN: 48 97099 30055 7

© 2020 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)

\* \*\*Based on test result by international testing and certification agency BV under laboratory conditions.