



Philips
Dispenser

Bottom loading
one nozzle
Micro P-Clean filtration

ADD4965SV

Bottle water redefined

With micro P-Clean filtration*

With micro P-Clean filtration system, this bottled water dispenser effectively removes microplastics* to ensure the cleanness of water.

Cleaner water

- Micro P-Clean filtration effectively removes microplastics*
- Long-life filter with a capacity of 4000L***

Thoughtful design for your convenience

- ClearSmart indicator tells when to replace the filter
- Compressor cools water efficiently
- Wide dispensing area fits various sizes of containers
- QuickTwist filter change for easy filter replacement
- Z-shape 304 stainless steel water pipe

Safeness assured

- Child lock to prevent hot water burns

PHILIPS

Dispenser
Bottom loading one nozzle, Micro P-Clean filtration

Specifications

Filter specifications

- Main filter media: Carbon block
- Filter precision: 1 micro
- Filtration capacity: 4000L
- Replacement filter cartridge: ADD502

General specifications

- Cold water temperature: 10 °C

- Voltage and frequency: 220V-240V~, 50Hz/60Hz
- Hot water temperature: 90 °C

Power

- Cooling: 85W
- Heating: 500W

Country of origin

- Water dispenser: China

ADD4965SV/56

Highlights

Micro P-Clean filtration

Cleaner water assured with effective microplastics removed*, thanks to the Micro P-Clean filtration system which comes with a fine filtration precision of 1 micro.

Long-life filtration

The MicroClean filter has a filtration capacity of 4000L, which lasts for about 1 year***.

ClearSmart filter indicator

ClearSmart indicator reminds you of on-time filter replacement to ensure the water quality. When the filter is approaching the end of life, the indicator starts to flash, and turns red when the filter lifetime ends.

QuickTwist filter change

QuickTwist filter change for easy filter replacement; no professional service needed.

Compressor cooling

Compressor cooling produces cool water more efficiently and faster, compared to conventional thermoelectric cooling.

Wide water dispensing area

Wide dispensing area easily fits various sizes of cup, glass, bowl and even pot.

Z-shape water pipe

The 304 stainless steel water pipe is anti-rust, and the Z-shape helps to reach the bottom of the bottle so that there's no remaining water.

Child lock for hot water

Child lock for hot water keeps children safe from accidental hot water burns.



Issue date 2023-12-27

Version: 3.0.1

EAN: 48 97099 30227 8

© 2023 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com

* Tested according to NSF testing protocols by 3rd party
ISO9001:2015 accredited laboratory with particles down to 2
microns.

**Tested by internal laboratory. Assuming water consumption of
10L per day.