

Stand Steamer

Max 6 bar pump pressure Up to 90g steam boost No descaling needed OptimalTEMP heated plate



# GC625/26

# Great results in just one stroke, no wet spots

# with innovative Dual Heating Technology

Thanks to the innovative Dual Heating technology, the new PerfectCare garment steamer ensures powerful steam performance with no wet spots for great results effortlessly.

# **Ultimate convenience**

- Maintenance free engine, no descaling needed\*
- Wheels for easy transportation
- Easy steam selection (3 settings+ ECO) on handle

# Reliable

- PVC free hose
- Steam refreshes garments and kills 99.9% of bacteria\*
- · Automatically switches to standby mode for peace of mind

## Fast de-wrinkling for great results

- OptimalTEMP heated plate, guaranteed no burns\*
- Triple precision tips on steam plate for challenging areas

**PHILIPS** 

- Dual Heating Technology
- Powerful & continuous steam
- · Stable tilting board with quick dry cover

# Highlights

# **Dual Heating Technology**



The innovative Dual Heating technology generates steam instantly at the base and reheats at the steamer head, for powerful penetrating steam, giving great results with no wet spots

# **OptimalTEMP** heated steam plate



Steamer plate is actively heated to provide better de-wrinkling results with no wet spots. With OptimalTEMP technology, it guarantees no burns on all ironable fabrics.

## Powerful & continuous steam



90g powerful steam boost penetrates deep into garments while 35g/min of continuous steam enables effortless wrinkle removal, for great de-wrinkling results.

# **Triple precision tips**



The triple precision tips on the steamer head enable you to reach the challenging areas, such as the collar, the shoulder, and the in-between buttons, giving you precise results.

# Tilting board &quick dry cover



It can be tilted 30°, giving stable and comfortable support to make pleats and achieve crisp results. The shoulder shape board provides a better fit for garments. Board comes with a quick dry cover with enhanced steam permeability and breathability. It is durable with high heat resistance.

#### Maintenance free engine



Steamers need to be descaled regularly to ensure steam performance. Our new

innovative engine prevents scale from building up, for long lasting steam performance.

### Easy steam selection on handle



By pressing the steam selection button on the handle, you can easily change steam level for different fabrics - no need to bend down! Set your preferred steam level for optimal results on different fabrics. Use low steam for thinner fabrics and a more powerful setting for thicker fabrics and coats. Use ECO mode to save energy consumption.

#### Wheels for easy transportation



# transportation

Wheels enable user to tilt and drag the stand steamer from one place to another easily.

#### Auto shut off

The steamer automatically switches to standby mode when the water tank is empty, so you have peace of mind even if you forget to switch it off.

#### Easy to use

- · Water tank capacity: 2000 ml
- Detachable water tank
- Refill any time during use
- Tap water suitable
- Power cord length: 1.8 m
- · Precision steam tip
- · Select steam level from handle
- Special water inlet: For extra hygiene
- Auto shut off
- · Safe on all fabrics: Even delicates like silk PVC Free Hose

#### Technology

- OptimalTEMP technology
- For all ironable fabrics
- No burns

#### **Accessories included**

- Adjustable pole
- · Glove for extra protection

#### Fast crease removal

- Power: 2200 W
- Steam boost: up to 90 g
- Continuous steam: 35 g/min
- Vertical steam
- Voltage: 220-240 V
- Ready to use: 2 minute(s)
- Variable steam: 3 levels

- Steam-on-demand
- Pressure Bar: Max 6 bar pump

### Storage

· Integrated wheels: For easy transportation

#### Size and weight

- Board size (WxHxL): 41 x 74.5 x 5.1 cm
- Packaging dimensions (WxHxL): 46.5 x 51 x
- 61.5 cm
- Weight of iron: 0.69 kg
  Cover size (WxHxL): 42.2 x 75.7 x 6.3 cm
- Weight of board: 1.7 kg
  Product dimensions (WxHxL): Base dimensions : 32 x 45.2 x 34 cm
- Total weight with packaging: 11.5 kg
- Foam layer thickness: Cover thickness : 6 mm mm
- Ironing surface: 56.4 cm
- Weight of iron + base: 6.78 kg
- · Pole dimensions extended: Height from ground to shoulder tip of Hanger : 155 cm

#### **Green efficiency**

- · Energy saving mode
- Product packaging: 100% recycable
- User manual: 100% recycled paper

#### Guarantee

• 2 year worldwide guarantee



Issue date 2022-10-07

© 2022 Koninklijke Philips N.V. All Rights reserved.

Version: 1.1.1

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

\* On all ironable fabrics

GC625/26

- $^{*}$  tested to IEC protocol with hard water for 500 hours to simulate 5 years of usage.
- tested by third party institute for bacteria types Escherichia coli 8099, Staphylococcus aureus ATCC 6538, Candida albicans ATCC 10231 with 1 minute steaming time (Technical Standard For Disinfection 2002-2.1.5)

EAN: 08 71010 39251 32 www.philips.com