

PHILIPS

Water filter pitcher

Microfiltration

GAC + ion-exchange resin

1.5 L tank for filtered water

AWP2915



Clean water made easy

Microfiltration system reduces lead and chlorine

With a multi-stage microfiltration system, this water filter pitcher reduces VOCs and pesticides and removes up to 99% of chlorine and lead for healthy and tasty drinking water*. It also reduces water hardness.

Cleaner water

- Effectively reduces lead, pesticides, VOCs and chlorine

Made easy

- Dust-proof spout keeps water fresh and clean
- Simply discard the one-piece filter after use

Highlights

One-piece disposable filter

Simply discard the one-piece filter when it reaches the end of its service life. The one-piece design prevents secondary pollution.

Dust-proof spout

By preventing dust from getting in through the water outlet, the dust-proof spout keeps the water fresh and clean.

4-stage microfiltration

The 4 stage filtration system consists of non-woven fabric, granular activated carbon, resin and another layer of non-woven fabric, which effectively reduces pesticides, chemicals, microplastics and up to 99% lead* and chlorine for crisp and pure-tasting water. It also reduces water hardness.

Specifications

Filtration performance

Chlorine reduction: Yes, up to 99%*

Soluble lead reduction: Yes, up to 99%*

Bacteria removal: N/A

Water hardness reduction

Filter specifications

Main filter media: Granular activated carbon/GAC, Ion-exchange resin

Filtration capacity: 200 L

Input water conditions

Input water pressure: (atmospheric) 0-1 bar

Input water quality: Mains tap water

Input water temperature: 5-38 °C

General specifications

Replacement filter cartridge:

AWP200/AWP201

Water flow rate: 0.25 L/min

Country of origin

Filter: China

Pitcher: China

