



Philips  
Electric water heater

30 L, Storage  
2000 w

AWH1620

## Safety and comfort in your bathroom

### Comfortable and safe operation

The Philips electric water heater provides comprehensive protection. High-quality materials with additional protection help the water heater last longer. Step-heating technology provides fast heating with minimal energy consumption.

#### **Safety in your bathroom**

- RCD will provide your electrical protection
- Dielectric Couplings Static CARE

#### **User-friendly design**

- The indicator is highlighted on a convenient display.
- The digital display provides enhanced functionality for the user

#### **Step-heating technology for a faster bath**

- With a power of 2 kW provides fast water heating.

#### **High energy efficiency and energy saving**

- Remains a reduced temperature of 55 degrees Celsius

#### **Extended water heater life**

- DRY SHELL heating element is not in contact with water
- Water heater protection anode increased by 40%
- High-quality stainless steel inner tank

# PHILIPS

Electric water heater  
30 L, Storage 2000 w

# Specifications

## General specifications

- gross weight: 12 kg
- Product Dimensions (LxWxH): 433\*550\*236 mm
- net weight: 10.5 kg
- Packaging Dimension(L)\*(W)\*(H): 490\*635\*300 mm

## Main parameters

- Colour: White
- Control type: Mechanical control
- Rated Power: 2000 W

- Capacity: 30 L
- Voltage and frequency: 220-240/50 Hz
- Installation way: Vertical installation
- Heating type: Single heating element, Casting-aluminium heater

## Country of origin

- Made in: China

## Service

- Warranty period: 2 years

AWH1620/51

# Highlights

## Your electrical protection

In the event of an electrical leakage, the residual current device will cut off the power to the water heater.

## Non-contact heating element

The heating element is placed in an outer housing that protects it from water, scale and corrosion. The outer housing is covered with a SHELL glass-ceramic coating.

## Oversized Anode

The magnesium anode is increased by 40% compared to normal anodes. The anode catches the currents, preventing the walls of the tank from collapsing.

## Static CARE protection

Static CARE dielectric couplings will protect you and your loved ones from static current, as well as the electronic parts of the device.

## OptimalTEMP mode

Set the temperature control knob to the "OptimalTEMP" position and the water heater will always maintain a comfortable temperature of 55 degrees Celsius, while saving energy consumption.

## Stainless steel inner tank

The inner tank is made of high-quality stainless steel, is corrosion resistant and does not emit harmful substances when heated.

## Two-stage heating technology

The adjustable power of the two-stage heating element allows you to quickly heat the water in an energy-saving way.

## Digital display

Using the digital display can set the water heating time and the timer. To do this, select one of the appropriate modes and then you can set the water temperature with an accuracy of 1 degree Celsius.

## Mode indication

Using the digital display can set the water heating time and the timer. To do this, select one of the appropriate modes and then you can set the water temperature with an accuracy of 1 degree Celsius.



Issue date 2022-12-13

Version: 2.0.1

© 2022 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)