



Philips  
Mini massage gun

Small and cute  
Powerful massage function

PPM7301PK

## Enjoy body massage everywhere

Powerful system & professional accessories

Specially designed for women., it is super portable with its small size and light weight. With the well designed massage accessories and the powerful dynamic system, you can enjoy a real relaxing massage anytime and anywhere.

### Portable & cute design

- Occupied little space, you can bring it out without worries

### 10kg output power for real relaxing massage

- Up to 10kg massage pressure output

### Professional massage accessories

- Produce a penetrating wave to tissue and avoid harm to skin
- Comfortable and effective for relaxation and sport recovery
- 4 massage heads with different materials and shapes

### Shock resistant carry case

- Providing comprehensive protection by a hard shell package

# PHILIPS

Mini massage gun  
Small and cute Powerful massage function

# Specifications

## General specifications

- Gross weight: 900g
- Product dimension: 78\*142\*48mm mm
- Net weight: 380g
- Color: Pink
- Packaging dimension: 200\*145\*75 mm

## Main parameters

- Massage amplitude: 6mm
- Rated voltage: 7.4V

- Massage frequency: 1600Hz-3200Hz
- Battery: 7.4V 2600mAh×2
- Maximum thrust: 10kg
- Charging port: USB TypeC, DC 5V 2A

## Country of origin

- Made in: China

## Service

- Warranty period: 2 years

PPM7301PK/90

# Highlights

## Small & light weight

The 28mm super compact dynamic arm reduces the width of device to 78mm only, which you can put in a very small handbag. You can bring the device at ease with its 380g light weight.

## Powerful dynamic system

The well adjusted BLDC motor, combined with full-metal dynamic system, can provide a peak output of 10kg, which is necessary for deep tissue relaxation of big muscles.

## Physio massage accessories set

The 4 massage heads with different materials and shapes are designed under guidance of professional physio. They can satisfy the requirements of massage for different parts of body in different depth and strength.

## A physio titanium surface head

The titanium massage head can manage the deep tissue of big muscles and completely relieve the muscle group. Titanium will not cause the discomfort of people with skin allergy.

## A soft rubber massage head

High elastic rubber is applied to improve the massage depth and comfort level. It works together with the high frequency to achieve the best result for deep tissue massage. The enclosed surface of rubber is easy to clean. It can avoid bacteria and harmful substances infiltration to protect skin in long term use.

## Shock resistant carrying case

The high strength plastic hard shell carrying case is small and compact, anti falling and anti pressure, which provides all-round protection for the device.



Issue date 2022-12-13

Version: 1.0.1

© 2022 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)