



Philips
Filter cartridge

X-Guard Ultra

AWP315

Crisp and pure-tasting water straight from the tap

Enjoy crisp and pure-tasting water whenever you turn on the tap, with the Philips X-Guard ultrafiltration system reducing chlorine, lead, bacteria and more.

Crisp and pure-tasting water

- Effectively reduces chlorine, lead, bacteria and more

Made easy

- Quick twist design for easy filter replacement

Good for you and good for the environment

- Delicious water at a fraction of the cost of bottled water

PHILIPS

Filter cartridge
X-Guard Ultra

Specifications

Input water conditions

- Input water temperature: 5-38 °C
- Input water quality: Mains tap water
- Input water pressure: 0.15–0.35 Mpa bar

General specifications

- Filtration capacity: 1200 L

AWP315/10

Highlights

Easy filter replacement

Effortlessly replace the expired filter with a new one with a simple twist.

Economical and eco-friendly

Great-tasting water at a fraction of the cost and waste of bottled water.

X-Guard Ultra filter

By adopting the innovative activated carbon-fibre and hollow-fibre membrane, this X-Guard Ultra filter effectively reduces chlorine, lead, pesticides, microplastics and particles down to 0.1 micron. It also filters up to 99.99% of bacteria.



Issue date 2022-12-13

Version: 1.2.1

© 2022 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com