



Philips  
Replacement filter for on  
tap purifier

Micro X-Pure



WP3922

## Pure water made easy

### Micro X-Pure filter

Advanced filtration system based on hollow fiber membrane and ion exchanger that removes bacteria, harmful organic compounds, chlorine and lead. It improves taste and smell and preserves good minerals in your water.

#### **Pure water**

- Removes bacteria, soluble lead & harmful organic compounds

#### **Made easy**

- Advanced Quick Twist mechanism for easy filter replacement

# PHILIPS

# Specifications

## Purification system

- Bacteria removal: 99.99 %
- Turbidity removal: 3000 liters or approx. 1 year
- VOC Removal
- Pesticides removal
- Chlorine removal: >75 %
- Hormones removal

## Design specifications

- Color(s): white
- Materials: plastic
- Product weight: 180 g
- Product dimensions (L x W x H): 60 x 64 x 105 mm

## Filter specifications

- Filter lifetime: 1500 L or approx. 3 months
- Major filter components: hollow-fiber membrane,

granular activated carbon GAC, ion exchange resin, pre-filter of sediments

## Input water conditions

- Min. input water pressure: 0.7 bar
- Max. input water pressure: 3.5 bar
- Max. input water temperature: 50 °C

## General specifications

- Water flow rate: 1.6 l/min
- Water flow rate: 5 °C

## Sustainability

- Packaging: > 90% recycled materials

## Country of origin

- Replacement filter: Japan

# Highlights

## Micro X-Clean filter

The Micro X-Clean is multi-filtration system. It consists of a hi-tech hollow-fibre membrane, which contains more than 300 billion micro-pores for the efficient removal of 99.99% of all bacteria, an ion exchanger to remove harmful soluble lead, a fine granular activated carbon to remove the harmful chlorination by-products, harmful industrial pollutants such as volatile organic chemicals, and agricultural pollutants such as the pesticide CAT. It also removes unpleasant chlorine, bad taste and odors. The filter preserves the good minerals in drinking water that are vital for human health.

## Quick Twist filter change

The advanced Quick Twist filter change mechanism makes changing the filter quick, easy and secure, bringing sense and simplicity to your water purifier.

