



Philips
Mini Back Massager

One-key control

Heating thermostatically
Lithium battery supply

PPM4301GN

Wireless massage, limitless relaxation

Enjoy unlimited massage.

Upgraded power supply by large-capacity lithium battery, the massager can be used without power cords. It relaxes your muscle and promotes blood circulation via two 3D nodes kneading and hot compress to make you deep relaxing experience.

Protective massage

- Three-dimensions massage makes comfortable experience
- Heating helps blood circulation and muscle soothing
- Timing to prevent hurt from over massaging and overheating

Multiple modes switch with one key

- Selecting modes to suit different needs
- Control the massager with just one key

No wires, no restraints

- Supply with lithium battery, get free from power cords

Various ways, easy to use

- Bring better experience via soft and skin-friendly fabric
- Compact body can play different roles
- A rabbit-like appearance to match up multiple massage needs

PHILIPS

Specifications

General specifications

- Heating type: Rice lights
- Product Dimension (LxWxH): 290 x 110 x 290 mm
- Color: Green
- Main materials: Elastic fabric

Main parameters

- Working voltage: 11.6V
- Auto shut-off time: 15 minutes

- Temperature of heating: 42 ± 3 °C
- Working power: 24W
- Charging current: 1A
- Charging voltage: 12.6V

Country of origin

- Made in: China

Service

- Warranty period: 2 years

Highlights

3D massage

Two 3D massage nodes are used, which can simulate the massage action of pushing, pulling and kneading by hand to make a more thorough massage.

4 massage modes

There are 4 modes: clockwise kneading, anticlockwise kneading, heating clockwise kneading and heating anti clockwise kneading. Various modes meet your need for relaxing different parts of body anytime. You can easily find out the massage experience that you prefer.

Hot compress

Thermostatically hot compress at about 42 degrees while kneading to enhance blood circulation, relieve pains and soothe muscle.

Soft and skin-friendly

With wearable elastic fabric and short flannel, you can get a better touch and feel it soft and breathable.

Rabbit-like appearance

Designing in a rabbit-like appearance makes the massager contour to your body and allows you a comfortable massage.

One-key control

Make difficult things simple. Simplifying the operation of all setting with one key.

No restraints with power cords

Powered by a large-capacity lithium battery, it provides long-lasting battery life. You can get rid of the trouble of power cords, enjoy massage as well as relaxation anytime and anywhere.

Timing function

Auto shut-off after massaging 15 minutes to avoid injuries of muscle and skin by over massaging and over heating.

Various uses

With unique appearance and suitable materials, the massage has multiple uses. It can massage your neck, back, waist, thighs, calves and so on. You can use it as a back pillow as well as a nap pillow.

