



Philips  
Replacement filter

CP

AUT810

# Crisp and pure tasting water straight from the tap

Made by Philips carbon block and sediment filter 2-in-1, which effectively reduces large particles, heavy metals, VOCs, taste impairing substances and up to 99% of chlorine.

## Tasty water

- Be equivalent to the performance of 2 filters

## Crisp and pure tasting water

- Reduces large particles, heavy metals and more

## Made easy

- QuickTwist filter replacement

# PHILIPS

Replacement filter  
CP

# Specifications

## Filtration performance

- Chlorine reduction: Yes, up to 99%\*
- Soluble lead reduction: N/A
- Pesticides reduction
- VOC reduction

## Filter specifications

- Filtration capacity: CP: 3,650L

## Input water conditions

- Input water quality: Municipal tap water
- Input water temperature: 5-38 °C
- Input water pressure: 0.1-0.4MPa bar

## General specifications

- Recommend filter lifetime: up to 12 months

## Country of origin

- Replacement filter cartridge: China

AUT810/90

# Highlights

## 2-in-1 compound filter

The 2-in-1 composite filter consists of PP cotton and compressible activated carbon, it effectively absorbs large particles, rust, residual chlorine, color, odor and microorganism.

## CBPA filter

Carbon block and sediment (CBPA) filter 2-in-1 effectively reduces large particles, chlorine, pesticides, heavy metals, volatile organic compounds, and taste impairing substances.

## QuickTwist filter replacement

Horizontal placement and QuickTwist design for easy filter replacement; no on-site customer service required.



Issue date 2023-11-01

Version: 1.0.1

EAN: 48 95244 60623 3

© 2023 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)

\* \*\*Based on test result by international testing and certification agency SGS under laboratory conditions.