



Philips
Mini Head Massager

181g in net weight

Patented 4 synchronous claws
Soft & hard silicone claw sets
Three-proof performance

PPM1301PK

Small & cute, portable massage

Dry & wet massage, scalp care in pocket

Patented structure, large-scale kneading with silicone claws in different softness. High dustproof, waterproof and shockproof performance with mirror & skin-friendly touch paint. Safe & comfortable scalp massage and full relaxation anywhere.

Multi-scene use, full care of scalp health

- 1 meter anti-shock and anti-drop, no fear of daily collision
- 2 sets of massage heads, replaceable for multiple scenarios
- Food-grade silicone massage heads, safer relaxation
- IP67 dustproof and waterproof, supported wet and dry use

Small and light

- Small size and light weight, massage at any time

Unique massage experience

- 3 types massage frequency, be opportune for various needs
- Four-claw linkage, large-scale directional kneading massage
- Charging once, last for about one week

PHILIPS

Mini Head Massager

181g in net weight Patented 4 synchronous claws, Soft & hard silicone claw sets, Three-proof performance

Specifications

General specifications

- Gross weight: 0.31kg
- Net weight: 0.22kg
- Product Dimension (LxWxH): 90×90×56.5 mm
- Color: Peach pink
- Massage type: 4-claw kneading, Grasping, Pushing
- Packaging Dimension(L)*(W)*(H): 125*109*91 mm

Main parameters

- Rated Power: 5 W

- Rated voltage: 3.7V
- Massage modes: 3
- Massage Level: Gentle mode, Strong mode, Alternate mode

Country of origin

- Country of origin: China

Service

- Warranty period: 2 years

PPM1301PK/90

Highlights

IP67 dustproof and waterproof

Both the body and the charging port are applying IPX67 dustproof and waterproof design. The whole machine can be used normally when it is soaked in water, so there is no need to worry about water seepage damaging the performance. You can use it when taking a bath to massage the scalp, remove itching and deeply nourish the scalp.

2 sets soft&hard massage heads

With two sets of silicone massage claws in different softness, it is replaceable and wider in use. The soft and thick brush massages claws, with a soft texture, large touch surface, is comfortably fit, suitable for all-body kneading and relaxation to users with sensitive scalp. The medium-soft and thin brush massage claws, equipped with 100 contacts and moderate hardness, improve massage pleasure correspondingly. It is suitable for endurance users and scalp cleaning.

3 massage modes

Level 1 for gentle kneading in slow speed, is suitable for daily maintenance, relax the tense head muscles. 2 levels for fast and strong kneading, is suitable for relieving fatigue, releasing stress, and deeply relaxing the scalp. Alternating frequency kneading in level 3, soothe your tired body with different strength, help you quickly fall asleep, and deeply care for your body.

1 meter shockproof

Shockproof and 1 meter anti-drop performance, it can be used with shampoo to massage the scalp while rinsing, which gives you more thoroughly clean.

Exquisite, occupy little space

Ultra-thin body 35mm, about the weight of an apple, you will not feel it heavy for a long-time use. Round shape design, enjoy kneading and grasping as you like. It is cordless and portable to provide massage anytime, anywhere.

Food-grade silicone materials

The silicone massage head meets the FDA food-grade requirements. It is extremely friendly to sensitive scalp users, without chemical irritation, and will not cause allergies. It touches the scalp like a manual fingertips which has both softness and strength to avoiding scalp hurts and intertwined hair.

4-claw synchronization patent

Controlling the reasonable spacing of the grasping angle, the rocker can rotate 360 degrees regularly to generate kneading technique. It effectively increases the massage area to relax the tight scalp in a wide range.

Long battery life

After fully charged, the battery can last for one week with 15-minutes use a day. The head massager is suitable for multiple usage during business trips. Intelligent automatically shut off for 15 minutes, it can save power and give you secure massage.



Issue date 2022-12-13

Version: 1.0.1

© 2022 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com