



Philips
Dispenser

Bottom loading
Hot, cold and ambient water
UV
Micro P-Clean filtration

ADD4972BK

Bottled water redefined

With Micro P-Clean filtration and UV LED

With Micro P-Clean filtration, this water dispenser reduces up to 99% of microplastics to ensure the cleanness of water. It also comes with UV sterilization, eliminating up to 99.9% of bacteria and 99% of viruses in the cold water tank.

Cleaner water

- Micro P-Clean filtration effectively removes microplastics*
- Long-life filter with a capacity of 4000L***
- UV-LED kills 99.9% bacteria in the cold water tank**

Thoughtful design for your convenience

- Compressor cools water efficiently
- Dual heating powers for your selection
- ClearSmart indicator tells when to replace the filter
- QuickTwist filter change for easy filter replacement
- Wide dispensing area fits various sizes of containers
- Z-shape 304 stainless steel water pipe

Safeness assured

- Child lock to prevent hot water burns

PHILIPS

Dispenser

Bottom loading Hot, cold and ambient water, UV, Micro P-Clean filtration

Specifications

Filter specifications

- Replacement filter cartridge: ADD502
- Filter precision: 1 micro
- Main filter media: Carbon block
- Filtration capacity: 4000L

General specifications

- Voltage and frequency: 220V~ / 50Hz

- Cold water temperature: 10 °C
- Hot water temperature: 90 °C

Power

- Cooling: 85W
- Heating: 170W/350W

Country of origin

- Water dispenser: China

ADD4972BK/70

Highlights

Child lock for hot water

Child lock for hot water keeps children safe from accidental hot water burns.

Compressor cooling

Compressor cooling produces cool water more efficiently and faster, compared to conventional thermoelectric cooling.

Dual heating powers

Dual powers for your selection - 350W high power for fast boil, and 170W low power to save energy.

QuickTwist filter change

QuickTwist filter change for easy filter replacement; no professional service needed.

ClearSmart filter indicator

ClearSmart indicator reminds you of on-time filter replacement to ensure the water quality. When the filter is approaching the end of life, the indicator starts to flash, and turns red when the filter lifetime ends.

Long-life filtration

The MicroClean filter has a filtration capacity of 4000L, which lasts for about 1 year***.

Micro P-Clean filtration

Cleaner water assured with effective microplastics removed*, thanks to the Micro P-Clean filtration system which comes with a fine filtration precision of 1 micro.

UV disinfection

Since there's no chlorine, bacteria tend to grow in the water that sits inside the bottle or the cold water tank. Therefore we have the advanced UV-LED light technology installed in the cold water tank which kills up to 99.9% bacteria**. The UV-LED light activates for 1 hour once the dispenser is connected with power, and works for 1 hour for every 2 hours to make sure the water stay clean.

Wide water dispensing area

Wide dispensing area easily fits various sizes of cup, glass, bowl and even pot.

Z-shape water pipe

The 304 stainless steel water pipe is anti-rust, and the Z-shape helps to reach the bottom of the bottle so that there's no remaining water.



Issue date 2022-12-13

Version: 1.0.1

© 2022 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com

**Tested by SGS under laboratory conditions.

***Tested by internal laboratory. Assuming water consumption of 10L per day.